



Ben Liu  
 Mobile/ WeChat: +86-13705041170  
 FUZHOU SUNSHINE MACHINERY CO.,LTD  
 NO.6 Gulouyuan, Juyuanzhou Industrial Zone,  
 Jinshan Development Area, Fuzhou, Fujian, China.  
 Email: sales@primepowergenset.com  
<http://www.gensetengine.com>

### Cummins M11 engine Spare parts catalog

Part number	Description
3037536	PLUG,THREADED
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
4070529	
2863701	SEALO RING
3922794	SEAL,O RING
3076489	THERMOSTAT
186780	SEALTHERMOSTAT
3046200	SPIDER,JAW COUPLING
S2286	DRIVE SCREW
S300	
100099	SEAL,RECTANGULAR RING
100129	SCREWSOCKET HEAD CAP
103426	GASKETAIR COMPRESSOR
105375	NAMEPLATE
107460	CLIP
108330	WASHER,PLAIN
109080	SEALO RING
110855	GASKETFUEL PUMP
119364	GEARFUEL PUMPING
127316	WASHERPLAIN
128807	RINGRETAINING
129768	SPRINGVALVE
129839	COVER,SHUTOFF VALVE
129866	UNIONMALE
129888	SEALRECTANGULAR RING
139988	SEAL,RECTANGULAR RING
142207	DOWELPIN

144044	HOSEPLAIN
145527	SEALO RING
146483	SCREENROTOR
148555	DOWELPIN
151900	SEAL RECTANGULAR RING
153336	BODYFUEL PUMP DAMPER
153338	DAMPER FUEL CONTROL
153346	SCREWSOCKET HEAD CAP
160514	WASHER,PLAIN
170664	WASHERPLAIN
175865	SHAFTFUEL PUMP
179063	PLUGRETAINER
181466	WASHER,LOCK
196057	DISCVALVE
69911A	CLIP
202159	SCREWTWELVE POINT CAP
202897	DIAPHRAGM
203518	WASHERPLAIN
204048	PLATECOVER
5266422	GASKET,EXHAUST MANIFOLD
206326	SCREW,TWELVE POINT CAP
9245	SPACERSTARTING MOTOR
67946	WASHER,PLAIN
69324	WASHERPLAIN
70550	DOWELPIN
70700	SPRINGFUEL PUMP TORQUE
70704	WASHER PLAIN
3000173	SCREWHXAGON HEAD CAP
3000174	HUBSPLINE COUPLING
3007632	PLUGEXPANSION
3007635	PLUGEXPANSION
3008400	GASKETHYDRAULIC PUMP
3008446	DOWELPIN
3008465	PLUGPIPE
3008466	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3008470	PLUGPIPE
3008690	CLAMPHOSE
3009329	WASHERPLAIN
3009330	WASHERPLAIN
3009887	SCREWHXAGON HEAD CAP
3009953	KEYPLAIN WOODRUFF
3010146	SPRINGCOMPRESSION
3012481	SCREWCAPTIVE WASHER CAP

3013786	PLUGPIPE
3014575	CAPFUEL PUMP FILTER
3014754	WASHERPLAIN
3014755	DISCVALVE
3014756	SPRINGCOMPRESSION
3016652	RINGRETAINING
3016760	BEARING,CON ROD (STD)
3016770	BEARINGMAIN STD
3016780	BEARINGMAIN STD
3017051	SCREW,CAPTIVE WASHER CAP
3017502	SCREWHEXAGON HEAD CAP
3018006	SCREWHEXAGON HEAD CAP
3018671	SCREWHEXAGON HEAD CAP
3019617	GEAR & SHAFTGEAR PUMP
3019630	PLUGDRIVE
3021123	SEALO RING
3022148	SCREWHEXAGON HEAD CAP
3025295	COVERCAMSHAFT
3025296	GASKET,CAMSHAFT COVER
3025322	ADAPTERSPLINE
3025802	SCREWHEXAGON HEAD CAP
3026134	GASKETCOVER PLATE
3026135	COVERACCESS HOLE
3026166	SHAFTIDLER
3026167	SHAFTIDLER
3026195	PLUGTHREADED
3026231	DOWELRING
3026233	RETAINERGEAR
3026758	SEATPRS REGULATOR VALVE
3027106	DOWELRING
3027108	SCREWCONNECTING ROD CAP
3027924	GASKETCONNECTION
3028309	BEARINGTHRUST
3028684	COVERHAND HOLE
3031007	GASKETSTARTER
3031511	PLUGPIPE
3033719	DOWELRING
3033740	VALVECHECK
3033742	PLUGTHREADED
3034412	SEAL,O RING
3034451	HOUSINGACTUATOR
3034836	SCREWHEXAGON HEAD CAP
3036230	SCREWHEXAGON HEAD CAP
3037537	SEAL,O RING
3038996	GEARIDLER

3040815	PLUGTHREADED
3040817	SEALO RING
3041042	GEARACCESSORY DRIVE
3041247	WASHERPLAIN
3042401	SEALGROMMET
3042619	NIPPLECOUPLING
3044360	NUTREGULAR HEXAGON
3046201	SEALO RING
3046202	PLUG,THREADED
3047188	SEAL,RECTANGULAR RING
3047340	ELBOWMALE UNION
3049119	ELBOWMALE UNION
160586	RINGRETAINING
163654	SEALO RING
199358	SLEEVESPLINE COUPLING
205363	WASHERSPRING
206741	PLUGEXPANSION
206963	INSERTFILTER HEAD
2863702	SEALO RING
2864080	GASKETCYLINDER HEAD
3007759	SEALO RING
3016761	BEARINGCON ROD 010
3016762	BEARINGCON ROD 020
3016763	BEARINGCON ROD 030
3016764	BEARINGCON ROD 040
3016771	BEARINGMAIN 010
3016772	BEARINGMAIN 020
3016773	BEARINGMAIN 030
3016774	BEARINGMAIN 040
3016781	BEARINGMAIN 010
3016782	BEARINGMAIN 020
3016783	BEARINGMAIN 030
3016784	BEARINGMAIN 040
3019600	SEALOIL
3019631	WASHERPLAIN
3019733	BUSHING
3025130	GASKETLUB OIL PUMP COVER
3025354	BEARINGNEEDLE
3026156	WASHERPLAIN
3026188	BUSHING
3026189	BUSHING
3026961	CAP,MAIN BEARING
3028252	PINROLL
3028295	SEALRECTANGULAR RING
3028422	GEARHYDRAULIC PUMP

3029920	PINROLL
3032787	SEALO RING
3033247	SEALO RING
3033248	SEALO RING
3033724	BUSHING
3035679	IMPELLERWATER PUMP
3038991	GEARWATER PUMP
3039398	SCREWHEXAGON HEAD CAP
3040810	
3041043	SHAFTACCESSORY DRIVE
3041048	SHAFTACCESSORY DRIVE
3042004	PLUGTHREADED
3042327	WASHERLOCK
3042618	NIPPLECOUPLING
3042620	NIPPLE,COUPLING
3044896	COVERPROTECTIVE SHIPPING
3046943	SEAL O RING
3047134	TUBE BREATHER
3052198	SCREW SELF TAPPING METAL
3052956	ELBOW MALE UNION
3053349	DOWEL PIN
3055069	PLUG, THREADED
3056009	DISC ACTUATOR
3056415	SEALO RING
3056416	PLUG THREADED
3058568	WASHERLOCK
3062329	CLAMP WIRE TIE
3062626	COOLER ELECTRONIC CONTROL
3063779	PLUG THREADED
3064582	SUPPORT CAM FOL SHAFT
3064583	SUPPORT CAM FOL SHAFT
3064621	SOCKET TAPPET
3064634	RING RETAINING
3065151	GEAR FLYWHEEL RING
3065944	SCREW, CAPTIVE WASHER CAP
3066257	NUT REGULAR HEXAGON JAM
3066643	SOCKET TAPPET
3066644	SCREWS SLOTTED SET
3067871	BUSHING
3067941	PLUG BALL
3068390	ROD PUSH
3068768	RING RETAINING
3068979	PLUNGER PRS REGULATOR
3069020	LEVER ROCKER
3069728	SENSOR VISCOSITY

3069786	GASKETINTAKE MANIFOLD
3070072	GUIDESPRING
3070136	SEALO RING
3070137	SEALO RING
3070138	SEALO RING
3070175	CROSSHEADVALVE
3070393	SCREWHEX FLANGE HEAD CAP
3070486	SLEEVEINJECTOR
3073676	PULLEYCRANKSHAFT
3073698	COVERWATER PUMP
3073750	CLIP
2872429	SPACER,SEAL
3074317	SPACERSEAL
3076046	RODPUSH
3077444	CLAMPRETAINING
3079661	SUPPORTROCKER LEVER
3079662	SUPPORTROCKER LEVER
3080401	ADAPTERO RING
3080708	NOZZLEPISTON COOLING
3080722	SCREWHEXAGON HEAD CAP
3803703	KIT,LINER
3080769	SEALRECTANGULAR RING
3080770	SEALRECTANGULAR RING
3081273	DATAPLATE
3081347	SCREWHEXAGON HEAD CAP
3081348	SCREWHEXAGON HEAD CAP
3081350	SCREWHEXAGON HEAD CAP
3081950	UNION,MALE
3083817	PULLEYACCESSORY DRIVE
3084445	GEARCRANKSHAFT
3084447	GEAR,IDLER
3084532	GEAR,IDLER
3084533	GEARIDLER
3084568	CAMSHAFT
3084713	Seal, Oil
3084899	BEARING,THRUST
3085185	SENSORTEMPERATURE
3085615	RINGRETAINING
3088161	PLATETHRUST BEARING WEAR
3088978	INSERTVALVE
3088980	INSERTVALVE
3088984	GASKETTURBOCHARGER
3090996	SUPPORTFUEL PUMP
3102361	GASKETCONNECTION
3102500	SEALO RING

3102646	SEALO RING
3102802	SEALO RING
3095354	BRACEWIRING
3095355	HUBJAW COUPLING
3095356	SHAFTFUEL PUMP DRIVE
3095635	GEAR & SHAFTGEAR PUMP
3095798	STUD
3096077	GASKETFUEL PUMP
3096696	BRACEWIRING
3098721	HOUSING,ROCKER LEVER
3161025	SEALDUST
3161093	SCREWCAPTIVE WASHER CAP
3161475	LEVERCAM FOLLOWER
3161567	GER,PPG
3163713	SEALELECTRICAL CONNECTOR
3163714	SEALELECTRICAL CONNECTOR
3163715	SEALELECTRICAL CONNECTOR
3201386	GASKETAIR COMPRESSOR
3201659	SEALRECTANGULAR RING
3202049	SCREWHEXAGON HEAD CAP
3202101	PLUGTHREADED
3254405	SCREWHEXAGON HEAD CAP
3275354	COLLETVALVE
3318853	OIL FILTER
3328328	WASHERPLAIN
3328379	SCREWHEX FLANGE HEAD CAP
3328464	SEALRECTANGULAR RING
3328583	TUBELUB OIL SUCTION
3328617	SCREWHEXAGON HEAD CAP
3328637	SCREWHEX FLANGE HEAD CAP
3328687	SCREWCAPTIVE WASHER CAP
3328689	FLYWHEEL
3328740	SEALO RING
3328742	SCREWHEXAGON HEAD CAP
3328759	GASKETCARRIER
3328760	GASKETCARRIER
3328761	GASKET, CARRIER
3328948	GASKETEXHAUST MANIFOLD
3329066	HOUSINGENGINE HEATER
3330538	SEALO RING
3335044	SCREWHEXAGON HEAD CAP
3335152	MANIFOLDEXHAUST
3335342	PINCAM FOLLOWER ROLLER
3335343	PINCAM FOLLOWER ROLLER
3401165	TUBEFUEL DRAIN

3401167	ELBOWTUBE CONNECTOR
4318308	GASKETOIL PAN
3502231	SLINGEROIL
3519163	SCREWDRIVE
3521441	SEALSPLIT RING
3528094	BAFFLEOIL
3528096	PLATEOIL SEAL
3529372	NUTREGULAR HEXAGON
3529852	CLAMPV BAND
3533038	SHIELDTURBOCHARGER HEAT
3534109	COLLARTHURST
3534833	BEARINGTURBOCHARGER
3535399	CLAMPV BAND
3535704	HOUSINGTUR BEARING
3535983	WHEELTURBOCHARGER
3536942	HOUSINGTURBINE
3537782	HOUSINGCOMPRESSOR
3558515	GASKETHYDRAULIC PUMP
3600825	CONNECTIONAIR INTAKE
3617958	NUTREGULAR HEXAGON
3627695	SEAL,O RING
3678786	SEAL,O RING
3678912	SEAL,O RING
3709510	RINGRETAINING
3723863	RINGRETAINING
3755843	GASKETTURBOCHARGER
3758848	SEALSPLIT RING
3760250	NUTLOCK
3762915	SEALO RING
3803477	KITSEAL
3803682	HARNESSWIRING
3803894	KITSEAL
3803977	SET,PISTON RING
3804304	KITSEAL
3804557	KITTUR REPAIR
3818060	SCREWCAPTIVE WASHER CAP
3818121	SCREW,HEX FLANGE HEAD CAP
3818124	SPACERMOUNTING
3818229	SCREWHEXAGON HEAD CAP
3818463	WASHERPLAIN
3818823	STUD
3818824	NUTREGULAR HEXAGON
3818841	GASKETTHERMOSTAT HOUSING
3818849	SHAFTSHUTOFF VALVE
3818885	SEAL,O RING



3819448	SCREWCAPTIVE WASHER CAP
3819475	TUBE BREATHER
3819521	SCREW HEX FLANGE HEAD CAP
3819632	SHAFT WATER PUMP
3819638	ADAPTER HYDRAULIC PUMP
3819721	ELBOW MALE ADAPTER
3819722	ELBOW MALE ADAPTER
3819767	HEAD CORROSION RESISTOR
3819774	SLEEVE WEAR
3819871	SEAL O-RING
3819900	GASKET TURBOCHARGER
3820030	SEAL RECTANGULAR RING
3820186	SCREWCAPTIVE WASHER CAP
3820320	PLUNGER BYPASS VALVE
3820470	COVER HAND HOLE
2878168	BUSHING
3820629	GASKET FILTER HEAD
3820631	RING RETAINING
3820667	HOSE, PLAIN
3820749	INSERT THREADED
3820754	SUPPORT HYDRAULIC PUMP
3820782	RING RETAINING
3820791	SEAL O-RING
3820831	SCREWS SQUARE HEAD SET
3820872	GASKET COVER PLATE
3820918	SLEEVE WEAR
3820922	GSK, CPR
3820945	SEAL RECTANGULAR RING
3820946	SEAL RECTANGULAR RING
3820988	SCREW HEXAGON HEAD CAP
3821676	SCR, CAP
3821718	TUBE WATER TRANSFER
3821725	PLUG RETAINER
3821783	SCREWCAPTIVE WASHER CAP
3822067	SCREWCAPTIVE WASHER CAP
3865312	SENSOR TEMPERATURE
3865323	
3867043	SEAL O-RING
3882513	SPACER MOUNTING
3882528	RETAINER, GEAR
3882585	PLUG EXPANSION
3882586	SPRING COMPRESSION
3882793	SCREW TWELVE POINT CAP
3882885	WSH, PLA
3882893	TAPE

3882922	SCREWTWELVE POINT CAP
3883123	SCREWHEX FLANGE HEAD CAP
3883150	SEALO RING
3883220	GASKETROCKER LEVER COVER
3883222	SPACERMOUNTING
3883245	NUTREGULAR HEXAGON
3883284	SEAL,O RING
3883324	PULLEYACCESSORY DRIVE
3883367	HOUSINGENGINE HEATER
3883394	SCREWHEXAGON HEAD CAP
3883397	SCREWSTUDDED HEXAGON CAP
3883472	GSK,HOL
3883510	SEALRECTANGULAR RING
3883512	RETAINERSPRING
3883586	BRACKETLIFTING
3883598	CLAMPWIRE TIE
3883622	
3883777	BRACETUBE
3883780	HOSEFLEXIBLE
3883977	PIPEAIR TRANSFER
3892095	SEALO RING
3892105	SCREWCAPTIVE WASHER CAP
3892106	SCR,CAP
3892625	GASKETOIL COOLER SUPPORT
3892648	CLAMPV BAND
3892692	SCREWCAPTIVE WASHER CAP
3892697	
3892978	HOSEFLEXIBLE
3893584	SUPPORTROCKER LEVER
3893655	DATAPLATE
3893690	GASKETHEATER HOUSING
3893692	GASKETSUPPORT
3893721	TAPE
3893752	RINGCOMPRESSION PISTON
3893834	SCREWHEXAGON HEAD CAP
3893913	BEARINGNEEDLE
3895023	SEALDUST
3895438	SCREWHEX FLANGE HEAD CAP
3895439	SPACERMOUNTING
3895440	SCREWHEX FLANGE HEAD CAP
3895479	PLUGEXPANSION
3895488	ROLLERCAM FOLLOWER
3895718	PLUGRETAINER
3895736	COVER,WATER HEADER
3895830	SUPPORTCAM FOL SHAFT

3895831	SPT,SFT
3895832	STUD
3895833	SFT,FOL
3895836	
3895860	SPRINGVALVE
3896010	SUPPORTHEAT EXCHANGER
3896022	RETAINERADJUSTING SCREW
3896043	PLATECLAMPING
3896046	SUPPORTACCESSORY DRIVE
3896191	SUPPORTHEAT EXCHANGER
3896335	SUPPORTCAMSHAFT THRUST
3896444	BRACEFUEL PUMP
3896723	SCREWHEX FLANGE HEAD CAP
3896837	SEALDUST
3896894	BUSHING
3899299	HOSEFLEXIBLE
3899343	GASKETTURBOCHARGER
3899413	RINGCOMPRESSION PISTON
3899450	ROD,ENGINE CONNECTING
3899746	GASKETACC DRIVE SUPPORT
3899757	SCREWHEXAGON HEAD CAP
3899798	ISOLATORNOISE
3900589	NUTHEXAGON FLANGE
3900629	SCREWHEX FLANGE HEAD CAP
3900635	SCREWHEX FLANGE HEAD CAP
3900636	SCREW,HEX FLANGE HEAD CAP
3901865	SCREWHEX FLANGE HEAD CAP
4004911	SEALWATER PUMP
4022545	HOSEFLEXIBLE
4022868	HARNESS,ETR CNT MDL WRG
4022870	HARNESS,ETR CNT MDL WRG
4022907	SCREWHEX FLANGE HEAD CAP
4023084	BEARINGTHRUST
4023204	BEARING,THRUST
4025120	SET,MAIN BEARING (STD)
4025162	KITCYLINDER
4070462	SCREWHEXAGON HEAD CAP
4070463	SCREWHEX FLANGE HEAD CAP
4082772	SCREWROUND HEAD CAP
4082974	PLUG,GEAR COVER
4083006	GASKETWATER HEADER COVER
4083121	SCREWHEX FLANGE HEAD CAP
4089542	KITSEAL
4089998	SET,LOWER ENGINE GASKET
4902720	SENSOR,PRESSURE

4920751	
4952625	GASKET,AIR COMPRESSOR
3059408	THERMOSTAT (3059408)
4955665	KIT,SEAL
4970037	HOSE,PLAIN
4988280	
64816A	DOWELPIN
S112	SCREW,HEXAGON HEAD CAP
S16002	BEARING, BALL
2871314	GASKETHAND HOLE
3895020	SEAL, DUST
3892794	SEAL, OIL
4962745	SEAL, OIL
3803717	ASSEMBLY, CYLINDER BLOCK
3801279	CAP, MAIN BEARING
3027490	CAP, MAIN BEARING
3821160	LEVER, CAM FOLLOWER
3079589	LEVER, CAM FOLLOWER
3084448	GEAR, IDLER
3038995	GEAR, IDLER
BB2706-01	MAIN BEARINGS
4023083	BEARING, THRUST
4023203	BEARING, THRUST
3883042	SEAL, O RING
S3193	PIN, GROOVE
3803727	KIT, OIL SEAL
3883620	SEAL, OIL
3883659	GASKET, CARRIER
3899702	HOUSING, FLYWHEEL
3090942	PUMP,FUEL 3090942-Z003
3054608	SOLENOID
3085614	SPRING, COMPRESSION
3085613	PLUNGER, PRS REGULATOR
3068889	GEAR, FUEL PUMP
3033714	HOUSING, FUEL PUMP GEAR
3068770	COVER, FUEL PUMP GEAR
3071643	SEAL, OIL
3328688	FLYWHEEL
3893964	SEAL, RECTANGULAR STRIP
3892666	PLUG, GEAR COVER
3161006	SCREW, HEX FLANGE HEAD CAP
4025151	KIT, STRIP SEAL
3355173	BRACKET, LIFTING
3080400	RETAINER, CONNECTION
3892253	TAG, INSTRUCTION

3078151	SENSOR, POSITION
3078150	SENSOR, POSITION
3085198	SENSOR, TEMPERATURE
3820214	GEAR, CAMSHAFT
3896970	ROD, ENGINE CONNECTING
3045850	SCREW, HEX FLANGE HEAD CAP
3161515	SCREW, HEX FLANGE HEAD CAP
3328925	GASKET, CYLINDER HEAD
3063843	PIN, PISTON
3883144	CLAMP, INJECTOR
3532807	BEARING, TUR THRUST
3537777	IMPELLER, TUR COMPRESSOR
3064600	ASSEMBLY, ROCKER LEVER
3064602	LEVER, ROCKER
3068350	ASSEMBLY, ROCKER LEVER
3064605	LEVER, ROCKER
3068351	ASSEMBLY, ROCKER LEVER
3064608	LEVER, ROCKER
3068948	LEVER, ROCKER
3803166	SHAFT, ROCKER LEVER
3820750	SHAFT, ROCKER LEVER
3896697	GASKET, RKR LEVER HOUSING
2864400	DECAL
3896190	TITANIUM BLACK PAINT
3067406	MANIFOLD, EXHAUST
3073692	SUPPORT, THM HOUSING
3883221	GASKET, ROCKER LEVER COVER
3818935	HEAD, CORROSION RESISTOR
3017499	SCREW, HEXAGON HEAD CAP
3895735	COVER, WATER HEADER
3899229	GASKET, WATER HEADER COVER
3882615	BODY, WATER PUMP
4004501	HARNESS, WIRING
4004573	HARNESS, ETR CNT MDL WRG
4004571	HARNESS, ETR CNT MDL WRG
3099354	HARNESS, ETR CNT MDL WRG
4059810	HARNESS, ETR CNT MDL WRG
4059814	HARNESS, ETR CNT MDL WRG
4004503	HARNESS, ETR CNT MDL WRG
4059812	HARNESS, ETR CNT MDL WRG
3803724	SHAFT AND PLUG
3882733	GASKET, OIL PAN
3073512	GUIDE, VALVE STEM
3073509	SEAL, VALVE STEM
3073510	SEAL, VALVE STEM

3161473	ASSY, CAM FOLLOWER LEVER
3895489	ROLLER, CAM FOLLOWER
3161651	HOUSING, GEAR
3161004	HOUSING, GEAR
3073587	DAMPER, VIBRATION
3896231	SCREW, HEX FLANGE HEAD CAP
3882674	SUPPORT, FRONT ENGINE
3095634	PUMP, GEAR FUEL
3804657	KIT, FUEL PUMP SUPPORT
3061665	BRACE, FUEL PUMP
3328822	SCREW, CAPTIVE WASHER CAP
3896055	CONNECTOR, MALE
3870815	SEAL, OIL
4070537	KIT, GEAR COVER
3895946	ASSEMBLY, LUB OIL FIL HEAD
3899699	HEAD, LUB OIL FILTER
3081359	COOLER, LUBRICATING OIL
3895756	PUMP, LUBRICATING OIL
3328767	PAN, OIL TLA
3328529	PAN, OIL
3080406	SENSOR, PRESSURE
3083716	SENSOR, PRESSURE
3408300	MODULE, ELECTRONIC CONTROL
3067497	COVER, PROTECTIVE
3080407	SENSOR, PRESSURE
3406613	NAMEPLATE
3084521	SENSOR, PRESSURE
3083715	SENSOR, PRESSURE
3096072	NAMEPLATE
3088863	HEAD, CYLINDER
3084652	HEAD, CYLINDER
3804533	VALVE, INTAKE
3080975	VALVE, INTAKE
3804534	VALVE, EXHAUST
3080976	VALVE, EXHAUST
3803976	KIT, ENGINE PISTON
3896031	PISTON, ENGINE TLA
3896030	TOP, PISTON
4070653	SKIRT, PISTON
3899561	RING, OIL
3095040	INJECTOR
3803938	TURBOCHARGER
3536995	TURBOCHARGER
3529312	DATAPLATE
3400971	LEVER, ROCKER (TLA)

3400967	LEVER, ROCKER
3335151	MANIFOLD, AIR INTAKE
3895455	HOUSING, THERMOSTAT
3895453	HOUSING, THERMOSTAT
3899908	HOSE, FLEXIBLE
3899909	CONNECTION, TUR OIL DRAIN
3401131	COVER, RKR LEV TLA NO FILL
3401130	COVER, ROCKER LEVER
3073696	PUMP, WATER TLA
3073697	PUMP, WATER
3401351	HARNESS, WIRING
3161573	HARNESS, WIRING (TLA)
129859	ELBOW,MALE UNION
186917	CLAMP,V BAND