



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

### Cummins QSK60 engine Spare parts catalog

Part number	Description
3647996	CABLE
3643839	VALVECHECK
3317428	ADITIVE
3643984	BEARING,CON ROD (STD)
4955807	KIT,WATER PUMP 4376080
3643960	SEAL,OIL
3643961	SHAFTWATER PUMP
4066277NX	SUPPORT, WATER PUMP HHP
4066057	SHAFTHYD PUMP DRIVE
4100624	SEAL,OIL 3649551
3644387	SCREW,HEX FLANGE HEAD CAP
3646200	GUIDE,VALVE STEM
3347937	SEALO RING
3922794	SEAL,O RING
3076489	THERMOSTAT
212161	ORING
3046200	SPIDER,JAW COUPLING
FS1006	FUIL WATER (original) FS1006
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
3081489	SEALOIL
4000730	UNIONMALE
S2268	FITTING,GREASE
S2286	DRIVE SCREW
S306	
S607	WASHER,LOCK
S610	WASHER,LOCK

S626	WASHER
105375	NAMEPLATE
107460	CLIP
114307	BRACE,TUBE
118226	SCREW,SOCKET HEAD CAP
125742	CLAMPT BOLT
129768	SPRINGVALVE
129839	COVER,SHUTOFF VALVE
129888	SEALRECTANGULAR RING
131026	SEALO RING
131584	PIN,ROLL
149273	HOSE,PLAIN
169834	CLIP
173086	GASKET,INJECTOR
181461	GOVERNORAIR COMPRESSOR
3521442	SEAL,SPLIT RING
3900634	SCREWHX FLANGE HEAD CAP
196057	DISCVALVE
69911A	CLIP
203933	PLUGEXPANSION
205129	DOWEL,RING
205168	WASHERPLAIN
205401	PLUGEXPANSION
206090	RINGRETAINING
206091	GEARENGINE BARRING
206195	SLEEVE,SPLINE COUPLING
8306	PINROLL
209773	CLAMP,HOSE
60985	HOSE,PLAIN
62279	SPACERMOUNTING
63223	HOSE,PLAIN
64709	SPACERMOUNTING
66747	SPACERMOUNTING
68152	CLIP
68189	CLIP
68425	CLIP
68445	PIN, GROOVE
69558	DOWELPIN
70415	SEAL,O RING
70700	SPRINGFUEL PUMP TORQUE
553044	BUSHINGREDUCING PIPE
3007635	PLUGEXPANSION
3010410	COVERACCESS HOLE
3014668	SEALO RING
3021420	SOLENOID,FUEL PUMP

3030207	RETAINER,DIPSTICK
3030774	HOSEELBOW
3030782	HOSEELBOW
3033629	PIN,ROLL
3035026	SEAL,O RING
3035228	SEALO RING
3036115	COVER,PROTECTIVE SHIPPING
3037537	SEAL,O RING
3040815	PLUGTHREADED
3040817	SEALO RING
3040818	PLUGTHREADED
3042542	SEAL,O RING
3042619	NIPPLECOUPLING
3045986	SEAL,O RING
3046201	SEALO RING
206092	SPRINGCOMPRESSION
206391	SCREWTWELVE POINT CAP
206506	NUTLOCK
216187	SEAL,O RING
2872254	SENSOR,PRESSURE
3007512	SEALO RING
3028349	SEALO RING
3030487	SPACERBEARING
3030768	HOSEHUMP
3033248	SEALO RING
3040816	PLG,THD
3040819	PLG,THD
3042620	NIPPLE,COUPLING
3043487	CLAMPHOSE
3045012	PLUGINJECTOR ORIFICE
3045045	PLUGINJECTOR ORIFICE
3046287	SPACERMOUNTING
3046943	SEAL O RING
3048625	SEAL,OIL
3048626	BEARING,ROLLER
3056508	SCREWDRIVE
3062329	CLAMPWIRE TIE
3063166	SEAL,O RING
3066855	NAMEPLATE
3066914	SEAL,O RING
206808	SEAL,GROMMET
3071719	SHIMFUEL PUMP GOVERNOR
3075658	SEAL,O RING
3076226	GASKETAIR COMPRESSOR
3079743	DOWELRING

3080223	CAPFUEL PUMP FILTER
3081514	BUSHING
3081534	COLLET,VALVE
3081695	SEAL,O RING
3082121	BEARINGTHRUST
3082132	GASKETCOVER PLATE
3082315	GASKETEXHAUST MANIFOLD
3082340	BEARINGMAIN STD
3082346	BEARINGMAIN STD
3082358	SEALO RING
3082396	CONNECTIONFUEL BLOCK
3082415	RINGRETAINING
3082416	SHAFTCAM FOLLOWER
3082427	SCREW HEX FLANGE HEAD CAP
3082437	BEARINGCAMSHAFT THRUST
3082438	DOWELRING
3082440	SCREW,HEX FLANGE HEAD CAP
3082443	CAP,MAIN BEARING
3085709	SEAL,O RING
3085972	BUSHING
3085973	BUSHING
3085978	BALLROCKER LEVER
3085980	SOCKETROCKER LEVER
3088386	SHIM
3089016	SCREWHX FLANGE HEAD CAP
3089019	SEAL,O RING
3089023	PLUGTHREADED
3089081	GEAR,CAMSHAFT
3089083	SHAFTIDLER
3089084	SHAFTIDLER
3089087	GEAR,IDLER
3089091	GEAR,IDLER
3089093	ADAPTERCRANKSHAFT
3089100	GEARACCESSORY DRIVE
3089104	SHAFTIDLER
3089105	GEAR,IDLER
3089121	GEAR,IDLER
3089127	SCREWHX FLANGE HEAD CAP
3089128	SCREWHX FLANGE HEAD CAP
3089173	BUSHING
3089177	SOCKETROCKER LEVER
3089191	NUTHEXAGON FLANGE
3089192	SCREWHX FLANGE HEAD CAP
3089193	SCREWTWELVE POINT CAP
3089194	SCREWTWELVE POINT CAP

3089201	DOWELRING
3089232	SCREWHEX FLANGE HEAD CAP
3089234	SCREWHEX FLANGE HEAD CAP
3089238	PLUGTHREADED
3089240	SEAL,O RING
3089247	GASKETCONNECTION
3089251	RINGRETAINING
3089259	SCREWHEX FLANGE HEAD CAP
3089261	GASKETWATER PUMP
3089262	GASKETWATER PUMP
3089271	NUTLOCK
3089281	RETAINERGEAR
3089296	SCREWHEX FLANGE HEAD CAP
3089298	HEADCORROSION RESISTOR
3089299	HEADCORROSION RESISTOR
3089314	SHAFTIDLER
3089316	SCREWHEX FLANGE HEAD CAP
3089318	GASKETFLANGE
3089319	GASKETFLANGE
3089320	RETAINERGEAR
3089321	SPACERMOUNTING
3089324	SCREWHEX FLANGE HEAD CAP
3089327	DOWELPIN
3089328	SCREWHEX FLANGE HEAD CAP
3089330	PLUNGERPRS REGULATOR
3089356	SCREW,HEX FLANGE HEAD CAP
3089365	SCREWHEX FLANGE HEAD CAP
3089378	DOWELPIN
3089379	DOWELDIAMOND
3089392	SEALO RING
3089409	BUSHING
3089412	PLUGORIFICE
3089415	RETAINERSHAFT
3089454	BUSHING
3089498	KEYSQUARE
3089499	SCREW,HEX FLANGE HEAD CAP
3089501	SEAL,RECTANGULAR RING
3089555	WASHERPLAIN
3089563	SCREWHEX FLANGE HEAD CAP
3089570	SPACERCRANKSHAFT
3089592	SCREWHEX FLANGE HEAD CAP
3089715	SHAFTROCKER LEVER
3089731	CONNECTIONWATER INLET
3089765	CLAMP,V BAND
3089869	SCREWTWELVE POINT CAP

3089886	SEALRECTANGULAR RING
3089891	SEALRECTANGULAR RING
3089946	TEEMALE UNION
3089955	GASKETCONNECTION
3089959	SCR CAP
3090007	SCREWRKR LEVER ADJUSTING
3090010	ROLLER,CAM FOLLOWER
3090159	ELBOWMALE UNION
3090171	CLAMPTUBE
3090400	UNIONMALE
3090495	COVERVALVE
3090769	SCREEN, FILTER
3093828	NUTHEXAGON FLANGE
3093936	SCREWHEX FLANGE HEAD CAP
3093937	SCREWHEX FLANGE HEAD CAP
3093957	SCREWHEX FLANGE HEAD CAP
3100308	RES,CRN
3171111	WASHERPLAIN
3171156	HOSEELBOW
3171170	GASKETCONNECTION
3171180	CONNECTIONEXHAUST OUTLET
3171181	NUTHEXAGON FLANGE
3171287	GASKETCONNECTION
3171320	CONNECTIONWATER OUTLET
3171332	FLEXPLATE
3171499	GASKETRKR LEVER HOUSING
3171693	SCREWHEX FLANGE HEAD CAP
3171695	GASKETCONNECTION
3171696	TUBEFUEL TRANSFER
3171711	CLAMPTUBE
3171713	SCREWHEX FLANGE HEAD CAP
3171715	SCREWHEX FLANGE HEAD CAP
3171722	UNIONMALE
3171784	BRACETUBE
3171790	HOSEPLAIN
3171818	UNIONMALE
3171839	TUBECOUPLING
3171868	TEEMALE UNION
3171963	WASHERSEALING
3172019	IMPELLERWATER PUMP
3175573	RINGRETAINING
3175768	ADAPTER,FILTER HEAD
3176218	DOWEL,RING
3177040	SHAFTSHUTOFF VALVE
3179035	GASKET,WTR TRF CONNECTION

3254315	CLAMPHOSE
3278093	PLUGPIPE
3278480	SCREWHEX FLANGE HEAD CAP
3279244	SCREWHEXAGON HEAD CAP
3281178	CLIP
3282074	NUTHEXAGON FLANGE
3282081	SCREWHEX FLANGE HEAD CAP
3328589	SEAL,O RING
3330202	SEALO RING
3330600	ACTUATOR,ETR FUEL CONTROL
3330602	ACTUATOR,ETR FUEL CONTROL
3330658	BODYCONTROL VALVE
3331752	RETAINER,VALVE SPRING
3331818	ELBOWMALE UNION
3331821	GASKETFUEL PUMP
3331834	SEALRECTANGULAR RING
3331855	NUTTUBE
3331872	ELBOWMALE UNION
3331873	UNIONMALE
3331876	TEEMALE UNION
3331881	COUPLINGREDUCING PIPE
3331969	GASKETFRONT COVER
3331970	GASKETGEAR COVER
3331976	SPRINGCOMPRESSION
3332001	COVERWATER HEADER
3332002	COVERWATER HEADER
3332059	UNIONMALE
3332085	GASKETOIL PAN COVER
3332136	UNIONMALE
3646085	GEAR,CAMSHAFT
3332143	GASKETCONNECTION
3332158	CONNECTION,WATER INLET
3332160	SEAL,O RING
3332164	CLAMPV BAND
3332174	SCREWHEX FLANGE HEAD CAP
3332175	SCREWHEX FLANGE HEAD CAP
3332183	GASKET,CONNECTION
3332194	FLANGE
3332234	SCREWHEX FLANGE HEAD CAP
3332291	GASKETROCKER LEVER COVER
3332297	GASKETACC DRIVE SUPPORT
3332298	GASKETHYDRAULIC PUMP
3332299	GASKETWATER PUMP
3332325	DRIVEACCESSORY
3332326	HOUSINGENGINE BARRING

3332383	SHAFTBARRING
3332391	GASKET,WATER PUMP
3336400	WASHERSEALING
3336566	NUTLOCK
3336636	PLUGTHREADED
3347907	ACTUATOR,ETR FUEL CONTROL
3347939	SEALO RING
3348444	VALVECHECK
3348458	BODYPRS REGULATOR VALVE
3348583	GASKETPRS RLF VALVE BODY
3348663	CLAMP INJECTOR
3348703	SEALO RING
3393258	ELBOWMALE ADAPTER
3393437	SEAL,O RING
3393557	ELEMENT,LU OIL FILTER
3393560	BEARINGBALL
3393561	RINGRETAINING
3393562	PINSTRAIGHT
3393565	SEAL,O RING
3393567	STRAINEROIL
3393569	SEAL,O RING
3393570	SEAL,O RING
3393571	SEAL,O RING
3393577	SEALORING
3393578	SEAL,ORING
3393580	SEAL,ORING
3393581	WASHERPLAIN
3393582	WASHERPLAIN
3393583	WASHERPLAIN
3393584	SEAL,ORING
3393586	SEAL,O RING
3393587	SEAL,O RING
3393591	DISC.
3393592	PAPER
3408282	SEAL VALVE STEM
3408345	SENSOR,TEMPERATURE
2894868	SENSORPRESSURE
4306987	SENSORPRESSURE
3408566	SENSORPRESSURE
3408653	SENSOR,FLUID LEVEL 4358900
3410392	ELBOWMALE UNION
3410782	TEEMALE UNION
3649838	GASKETWATER HEADER COVER
3410897	ROD,PUSH
3410940	HOSE,FLEXIBLE



3410941	HOSE,FLEXIBLE
3410965	HOSE,FLEXIBLE
3411146	COVERHAND HOLE
3411232	BRACKET LIFTING
3411289	CAMSHAFT
3411290	CAMSHAFT
3417238	SEALO RING
3502449	SEAL,RECTANGULAR RING
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519535	NUTLOCK
3519641	RINGRETAINING
3522597	PINROLL
3522904	LOCKPLATE
3523412	SEALSPLIT RING
3524418	SHIM
3524419	BAFFLEOIL
3527619	DATAPLATE
3534405	SEAL,RECTANGULAR RING
3536588	SHIELDTURBOCHARGER HEAT
3537301	RINGRETAINING
3537916	BAFFLETURBOCHARGER NOISE
3590386	CLAMPV BAND
3590435	SCREWSOCKET HEAD CAP
3590444	NUTLOCK
3590445	SPACERMOUNTING
3600596	SCREWTWELVE POINT CAP
3625826	NUTLOCK
3627412	CLIP
3627695	SEAL,O RING
3627799	CONNECTORMALE
3627803	CONNECTOR,MALE
3627961	SEAL,THERMOSTAT
3628411	COVERSTARTER FLANGE
3628524	HOSE,FLEXIBLE
3628553	BRACETUBE
3628554	BRACE,TUBE
3628585	BRACE,TUBE
3628604	PLUG,PIPE
3628605	PLUG,PIPE
3628745	WASHERPLAIN
3629168	PLUG,EXPANSION
3629451	CLIP
3629452	CLIP
3629453	CLIP

3630248	CONNECTIONWATER OUTLET
3630740	SEAL,O RING
3630969	GASKET,LUB OIL CLR HSG
3631471	ADAPTERO RING
3631754	SEAL,ORING
3631755	SEAL,ORING
3631756	SEAL,ORING
3631757	PINGUIDE
3631758	SPRING
3631759	PINCOTTER
3631760	PINSTRAIGHT
3631862	DISCAIR CONTROL VALVE
3631863	DISCCOUPLING
3631864	CONNECTIONADAPTER
3631865	RINGPISTON PIN RETAINING
3631921	COVERWATER TRANSFER
3631940	SEALO RING
3631958	ASSY,HYDRAULIC MOTOR
3631959	ASSEMBLYSHAFT & SPROCKET
3631960	ASSEMBLYSHAFT & SPROCKET
3632027	HOSE,FLEXIBLE
3632542	SHAFT,GOVERNOR
3632840	SEALO RING
3632970	CONTROLTHROTTLE
3633001	SEAL,O RING
3633002	COVERACCESS HOLE
3633004	WASHERPLAIN
3633027	SPRINGTENSION
3633325	SEAL,O RING
3633523	KITFILTER
3633527	ASSYROTOR BODY
3633971	CLAMPT BOLT
3633972	CLAMP,T BOLT
3634007	SEAL,WATER PUMP
3634008	BRACKETCONNECTION
3634019	PLUGEXPANSION
3634057	ADAPTERPLAIN PIPE
3634686	UNIONMALE
3634708	DRAINCOCK
3635129	HOSE,FLEXIBLE
3635130	HOSE,FLEXIBLE
3635131	HOSE,FLEXIBLE
3635269	HOSE,FLEXIBLE
3635316	SPACERMOUNTING
3635317	TUBEWATER DRAIN

3635341	TUBEAIR
3635353	GASKETTHERMOSTAT HOUSING
3635440	TUBEWATER TRANSFER
3635455	SPRINGVALVE
3635811	PUMP, WATER
3635814	HOUSINGGEAR
3635898	HOSE,FLEXIBLE
3635971	COVER,CAMSHAFT
3636016	ADAPTEROIL PAN
4332517	NUTHEXAGON FLANGE
3636278	PLATECLAMPING
3636285	BRACKETIDLER PULLEY
3636362	CONNECTIONOIL TRANSFER
3636415	TUBEWATER DRAIN
3637073	HARNESS,ETR CNT MDL WRG
3637074	HARNESS,ETR CNT MDL WRG
3637075	HARNESSETR CNT MDL WRG
3637132	TUBEWATER TRANSFER
3637487	PULLEYIDLER
3637488	SHAFTFAN HUB
3637489	SPACER,BEARING
3637780	TEEMALE UNION
3637819	TUBEWATER TRANSFER
3637822	TUBEWATER TRANSFER
3637825	TUBEWATER TRANSFER
3637826	TUBEWATER TRANSFER
3637870	GASKETFUEL CONNECTION
3637968	PLATECOVER
3637969	PRIMER,ENGINE LUBRICATING
3638014	CONNECTION,FUEL BLOCK
3638094	SCREWBANJO CONNECTOR
3638095	HOSEFLEXIBLE
3638453	BRACKETSENSOR
3638582	DRAINCOCK
3638583	DRAINCOCK
3638747	HEAD,CYLINDER
3638987	PUMP,LUBRICATING OIL
3639025	BRACKET,CHECK VALVE
3639026	HOSEFLEXIBLE
3639027	HOSEFLEXIBLE
3639516	BRACKETPUMP
3639540	BRACKETPUMP
3639541	BRACKETPUMP
3639988	HOSE,FLEXIBLE
3640458	CROSSHEAD, VALVE

3640694	CONNECTION,FUEL BLOCK
3678603	SEAL,O RING
3678606	SEAL,O RING
3678610	PLUGTHREADED
3678611	PLUGTHREADED
3678786	SEAL,O RING
3678791	PLUG,THREADED
3678838	PLUGTHREADED
3678846	SEAL,O RING
3678873	PLUGTHREADED
3678912	SEAL,O RING
3678921	PLUGTHREADED
3678923	PLUGTHREADED
3678925	SEAL,O RING
3679139	SEAL,O RING
3680057	NUTREGULAR HEXAGON JAM
3680437	SCREWHEX FLANGE HEAD CAP
3681065	SCREWHEX FLANGE HEAD CAP
3682701	ELBOW,MALE UNION
3865398	SEALO RING
3867393	SCREENFILTER
3867561	SENSOR,BLOWBY FLOW 5461522
3867640	SEALO RING
3867651	SEALO RING
4307148	SEAL,INJECTOR
3867737	VALVEPRESSURE RELIEF
3888312	CHEM. PKG. DCA65-L
3899390	SCREWSOCKET HEAD CAP
3900257	DOWELPIN
3900589	NUTHEXAGON FLANGE
3900626	SCREWHEX FLANGE HEAD CAP
3900627	SCREWHEX FLANGE HEAD CAP
3900629	SCREWHEX FLANGE HEAD CAP
3900630	SCREWHEX FLANGE HEAD CAP
3900635	SCREWHEX FLANGE HEAD CAP
3900637	SCREWHEX FLANGE HEAD CAP
3900679	SCREWHEX FLANGE HEAD CAP
3901249	SCREWHEX FLANGE HEAD CAP
3901445	SCREW,HEX FLANGE HEAD CAP
3901865	SCREWHEX FLANGE HEAD CAP
3901937	SCREWHEX FLANGE HEAD CAP
3902114	SCREWHEX FLANGE HEAD CAP
3902451	SCREWHEX FLANGE HEAD CAP
3902460	SCREW,HEX FLANGE HEAD CAP
3902662	NUTHEXAGON FLANGE

3903112	SCREWHEX FLANGE HEAD CAP
3903210	NUTHEXAGON FLANGE
3903464	SCREWHEX FLANGE HEAD CAP
3903990	SCREWHEX FLANGE HEAD CAP
3904446	SCREWHEX FLANGE HEAD CAP
3905372	SCREWHEX FLANGE HEAD CAP
3906216	NUTHEXAGON FLANGE
3910495	SCREWHEX FLANGE HEAD CAP
3910901	SCREWHEX FLANGE HEAD CAP
3913372	SCREWHEX FLANGE HEAD CAP
3913994	SEALO RING
3914407	SCREWHEX FLANGE HEAD CAP
3920447	SCREWHEX FLANGE HEAD CAP
3921851	SCREW HEX FLANGE HEAD CAP
3944593	SCREWHEX FLANGE HEAD CAP
3963982	WASHER,SEALING
3968475	SCREWHEX FLANGE HEAD CAP
3991084	NAMEPLATE
4000837	SCREW,HEX FLANGE HEAD CAP
4000843	BRACETUBE
4000844	BRACETUBE
4000847	NUTLOCK
4000866	TUBEWATER BYPASS
4000872	TUBEWATER INLET
4000877	VALVECHECK
4001044	HOSE,HUMP
4001095	SCREWHEX FLANGE HEAD CAP
4001096	DOWELPIN
4001156	BRACE,TUBE
4001213	HOSE,FLEXIBLE
4001224	TUBE,FUEL DRAIN
4001226	SCREWHEX FLANGE HEAD CAP
4001378	SCREW,HEX FLANGE HEAD CAP
4001416	PINPISTON
4001432	TUBEWATER INLET
4001506	HOUSINGFLYWHEEL
4001537	CLAMPWIRE TIE
4001633	CONNECTORMALE
4001756	VALVEPRESSURE REGULATOR
4002080	VALVEPRESSURE REGULATOR
4006223	GASKETFLYWHEEL HOUSING
4006284	UNIONMALE
4007034	DAMPER,VISCOUS VIBRATION
4007035	DAMPER,VISCOUS VIBRATION
4007058	HOSEFLEXIBLE

4007074	ELBOWMALE UNION
4007165	GASKETGEAR HOUSING
4007207	CONNECTORMALE
4007215	BRACKETPUMP
4007216	BRACKETCONNECTION
4007226	SCREWHEX FLANGE HEAD CAP
4007287	HARNESSWIRING
4007569	BEARINGTHRUST
4007584	CLAMPU BOLT
4007741	BUSHING
4007901	HOSEPLAIN
4010519	SEALO RING
4010577	SEALO RING
4015803	TUBELUB OIL SUPPLY
4015817	HOSE,FLEXIBLE
3649415	HOSE,FLEXIBLE
4015887	GEAR,CRANKSHAFT
4016021	BELT,V RIBBED
4016277	UNIONMALE
4016279	ELBOWMALE UNION
4016407	TUBEWATER BYPASS
4016419	HEADLUB OIL FILTER
4016421	HEADLUB OIL FILTER
4016422	PIPEHYD MOTOR RETURN
4016423	COVERCENTRIFUGE
4016424	BRACKETFILTER
4016425	TUBELUB OIL TRANSFER
4016441	HOSE,FLEXIBLE
4016442	HOSE,FLEXIBLE
4016468	DOWELPIN
4016660	SHIM
4016661	SHIM
4016700	SPACERMOUNTING
4016701	DOWELPIN
4016726	CAP,MAIN BEARING
4016906	ADAPTERO RING
4016955	WASHERPLAIN
4016987	PULLEYCRANKSHAFT
4017050	COVERPROTECTIVE
4017163	FLANGE
4017188	BRACKETOIL TUBE
4017212	TEEMALE UNION
4017238	POINTERTIMING
4017240	PLUG,EXPANSION
4017292	SEALD RING

4017295	COVERPROTECTIVE
4017427	STUD
4017434	SLEEVE,SPLINE COUPLING
4017508	TUBEAIR BALANCE
4017530	HUB SPLINE COUPLING
RCK4050246	CLUTCH, FAN
4017621	PLUG,EXPANSION
4017622	PLUG,EXPANSION
4017656	PLUGORIFICE
4024792	SET,MAIN BEARING (STD)
4025070	VALVE,EXHAUST
4061677	HUBJAW COUPLING
4065229	BRACKETFUEL PLUMBING
4065343	COVERPROTECTIVE
4065349	GASKETEXH OUT CONNECTION
4065385	HOSE,FLEXIBLE
4065444	HOSE,FLEXIBLE
4065488	CLAMP,V BAND
4065566	THERMOSTAT 3651379
4065615	GASKET,TURBOCHARGER
4065627	PLUGDRIVE
4065633	LEVERROCKER
4065636	LEVERROCKER
4065639	LEVERROCKER
4065718	BRACKETOIL TUBE
4065754	LEVER,CAM FOLLOWER
4065756	LEVER,CAM FOLLOWER
4065785	O RING
4065866	SCREW HEX FLANGE HEAD CAP
4065896	MANIFOLD EXHAUST
4065898	MANIFOLD,EXHAUST
4065900	MANIFOLD EXHAUST
4066038	GASKETINTAKE MANIFOLD
3649418	LUBRICATING OIL FILTER HEAD
4066112	SEAL,O RING
4066129	RETAINERSEAL
4066135	GASKETFILTER HEAD
4066136	GASKETFILTER HEAD
4066204	BRACKETWATER TUBE
4066212	HOSE,PLAIN
4066254	COVERGEAR
4066277	SUPPORTWATER PUMP
4066304	SUPPORTFRONT ENGINE
4066385	SUPPORTHYDRAULIC PUMP
4066544	SUPPORTAIR COMPRESSOR

4066599	PLUGRETAINER
4066750	BELT,V RIBBED
3648606	SOLENOID
4066825	COVER,THERMOSTAT HOUSING
4066827	GASKETTHERMOSTAT HOUSING
4066935	BRACEWIRING
4067011	BRACKETWIRING RETAINER
4067915	CABLE
4067917	CABLE
4080141	BELLOWS
4080151	COVEROIL PAN
4080158	BELLOWS
4080164	DOWELDIAMOND
4080234	CLIP
4080240	ROD,PUSH
4080242	SPACERMOUNTING
4080243	BRACKETWATER TUBE
4080251	BRACKETCONNECTION
4080262	HOSE,FLEXIBLE
4080265	BRACKETSHIPPING
4080326	INSERTVALVE
4080327	BRACKETSHIPPING
4080333	INSERTVALVE
4080343	SEAL,VALVE STEM
4080395	SPACERMOUNTING
4080396	PULLEYACCESSORY DRIVE
4080402	PULLEY,ACCESSORY DRIVE
4080404	SEAL,OIL
4080433	HOSE,FLEXIBLE
4080458	DIPSTICK
4080519	ADAPTERO RING
4080544	HOSE,PLAIN
4080556	CONNECTORTUBE
4080571	MANIFOLD,AIR INTAKE
4080572	MANIFOLD AIR INTAKE
4080573	GASKETAFTERCOOLER COVER
4085920	HOSE,FLEXIBLE
4085924	GASKETCAMSHAFT COVER
4085925	COVERCAMSHAFT
4085926	
4086073	PLUGTHREADED
4086074	VALVEPRESSURE REGULATOR
4086143	HOSEPLAIN
4086160	BRACKETSOLENOID
4086225	GASKETCYLINDER HEAD



4086561	HOSEPLAIN
4086562	HOSEPLAIN
4086563	HOSEPLAIN
4086588	CLAMPT BOLT
4086649	ROTAROR,VALVE
4086650	BRACKETOIL TUBE
4086653	HOSE,FLEXIBLE
4086695	COVERHAND HOLE
4086753	CLAMPRETAINING
4086754	HOSE,FLEXIBLE
4088180	VALVEETR CNT PRESSURE
4088181	VALVEETR CNT PRESSURE
4088186	PUMP, FUEL W/CAL CODE
4088274	DISCACTUATOR
4088734	SENSORPRESSURE
4954905	SENSOR,TEMPERATURE
4088863	HOUSINGACTUATOR
4089143	KIT,LINER
4089247	SET,PISTON RING
4089874	KIT,LOWER ENGINE GASKET
4098089	SCREW,HEX FLANGE HEAD CAP
4100433	FILTERBODY
4100481	RINGCOMPRESSION PISTON
4100552	CLIP
4100563	MOTOR,AIR STARTING
4100596	BREATHERCRANKCASE
4100637	HOSE,FLEXIBLE
4100641	ELBOWMALE ADAPTER
4100660	SEALO RING
4100675	CONNECTIONAIR CROSSOVER
4100676	CONNECTIONAIR CROSSOVER
4100685	COVERHAND HOLE
4100717	HOSEFLEXIBLE
4100720	HOSEFLEXIBLE
4100764	BRACKETOIL TUBE
4100767	TUBE BREATHER
4100771	PLUG,ORIFICE
4100827	HOUSINGROCKER LEVER
4100829	CONNECTIONWATER TRANSFER
4100845	PLUGO RING
4100846	CLAMPRETAINING
4100847	RINGRETAINING
4100863	TUBEWATER TRANSFER
4100866	TUBEWATER TRANSFER
4100877	BRACKETOIL TUBE

4100883	BRACKETOIL TUBE
4100983	GASKETGEAR COVER
4100991	BRACKETWATER TUBE
4101011	CORE,COOLER
4101023	CONNECTORMALE
4101028	BRACKETEXH CONNECTION
4101030	CORE,AFTERCOOLER
4101150	GASKETCONNECTION
4101256	SPACERMOUNTING
4101288	SCREWHEX FLANGE HEAD CAP
4101292	PLUGEXPANSION
4101322	BUSHING
4101345	MANIFOLD,EXHAUST
4101347	MANIFOLD,EXHAUST
4101349	MANIFOLD,EXHAUST
4101379	GASKETOIL PAN
4101401	LOCKPLATE
43828B	
4902720	SENSOR,PRESSURE
4905883	SPACERMOUNTING
4905885	INSERTTHERMOSTAT HOUSING
4916693	ADAPTER,FILTER HEAD
4916702	HEAD,FUEL FILTER
4916712	TUBE,WATER BYPASS
4916714	TUBE,WATER BYPASS
4916874	CONNECTION,OIL TRANSFER
4916878	TUBE,LUB OIL TRANSFER
4916879	SLEEVE
4916985	TUBE,WATER OUTLET
4917006	BRACKET,FAN
4917020	TUBE,FUEL DRAIN
4921411	MODULE,ELECTRONIC CONTROL
4921574	SEAL, O RING
4924463	RETAINER,CONTROL VALVE
4924516	HOUSING,THERMOSTAT
4924925	SWITCH,PRESSURE
4928121	HOSE,FLEXIBLE
4309440	HEAD,1 CYL COMPRESSOR
4951860	SWITCH,RELAY
4951861	BRACKET,RELAY
4951862	HARNESS,WIRING
4951863	CABLE,ELECTRICAL
4951864	SWITCH,MAGNETIC
4955384	KIT,INTAKE VALVE
4955686	KIT,TURBOCHARGER

4955781	KIT,ENGINE PISTON
4975427	SEAL,O RING
68138	CONNECTOR,MALE
68152B	CLIP
70183	RINGRETAINING
S16054	BEARING, BALL
S16069	BEARING, BALL
3678924	PLUG, THREADED
3089239	PLUG, THREADED
3678922	PLUG, THREADED
4006285	UNION, MALE
3331838	UNION, MALE
3090419	UNION, MALE
3678605	PLUG, THREADED
3678845	PLUG, THREADED
3408346	SENSOR, TEMPERATURE
4006772	SOCKET, CAM FOLLOWER
4065750	PIN, CAM FOLLOWER ROLLER
3331029	ACTUATOR, ETR FUEL CONTROL
3329676	VALVE, PRESSURE RELIEF
3867668	SPRING, VALVE
4001751	PLUNGER, FUL PRS REGULATOR
3598528	BEARINGTURBOCHARGER
3590377	SCREW,SOCKET HEAD CAP
3090469	VALVE, EXHAUST
3089716	SHAFT, ROCKER LEVER
4065632	LEVER, ROCKER
4065635	LEVER, ROCKER
3678602	PLUG, THREADED
3171819	UNION, MALE
3331819	ELBOW, MALE UNION
3171723	UNION, MALE
3408563	SENSOR, PRESSURE
4007208	UNION, MALE
3408654	SENSOR, FLUID LEVEL
3643480	TAG, INSTRUCTION
4066276	CONNECTION, WATER TRANSFER
3082057	BUSHING
4966842	DATAPLATE
4085917	LINER, CYLINDER
4066210	PLUG, BALL
3082417	SHAFT, CAM FOLLOWER
4066811	PLUGBALL
4065749	PIN, CAM FOLLOWER ROLLER
4065755	LEVER, CAM FOLLOWER

3089217	ROLLER, CAM FOLLOWER
4065757	LEVER, CAM FOLLOWER
4015886	GEAR, IDLER
3089089	GEAR, IDLER
4000790	GEAR, IDLER
3089214	BUSHING
4000791	GEAR, IDLER
3089107	BUSHING
3089122	GEAR, IDLER
3089123	GEAR, IDLER
4000793	GEAR, IDLER
3089315	BUSHING
3916071	SCREW, HEX FLANGE HEAD CAP
4066545	SUPPORT, HYDRAULIC PUMP
3410393	ELBOW, MALE UNION
3089021	PLUG, THREADED
3638767	NIPPLECOUPLING
3638768	NIPPLE, COUPLING
4088182	VALVE, PRESSURE REGULATOR
4001945	VALVE, CHECK
3408567	SENSOR, PRESSURE
4001757	BARREL, CONTROL VALVE
4002081	VALVE, PRESSURE REGULATOR
4007073	ELBOW, MALE UNION
4101324	COVER, GEAR
4016504	COVER, GEAR
3408557	SENSOR, PRESSURE
3329693	INSERT, THREADED
3330657	BODY, CONTROL VALVE
3408565	SENSOR, PRESSURE
4088735	SENSOR, PRESSURE
3640518	ROD, ENGINE CONNECTING
3640515	ROD, ENGINE CONNECTING
3639974	BUSHING
3171769	VALVE, INTAKE
4065481	VALVE, EXHAUST
4086626	HEAD, CYLINDER
3927220	SCREW, HEX FLANGE HEAD CAP
4065638	LEVER, ROCKER
3638083	PUMP, WATER
3682727	ELBOW, MALE UNION
3332137	UNION, MALE
3171840	REDUCER, TUBE FITTING
3171891	TEE, MALE UNION
3331837	ELBOW, MALE UNION

3331882	REDUCER, TUBE FITTING
3637779	TEE, MALE UNION
4066278	SUPPORT, WATER PUMP
4066279	SUPPORT, WATER PUMP
4919913	KIT, WATER PUMP REPAIR
4025140	SET, UPPER ENGINE GASKET
4089148	SET, LOWER ENGINE GASKET
4001053	BLOCK, CYLINDER
4016529	BLOCK, CYLINDER
3176663	SEAL, TAMPER PROOF
4016048	NOZZLE, PISTON COOLING
4080156	NOZZLE, PISTON COOLING
3331923	CRANKSHAFT, ENGINE
3089963	CRANKSHAFT, ENGINE
3331921	WEIGHT, CRANKSHAFT COUNTER
3171643	PLUG, GEAR HOUSING
3089090	GEAR, IDLER
4100642	ELBOW, MALE ADAPTER
3090192	ELBOW, MALE UNION
3331839	SEAL, FERRULE
3331840	NUT, TUBE
4916984	PIECE
3647131	DRIVEHYDRAULIC PUMP
3647119	GEAR
3646082	GEARACCESSORY DRIVE
4066373	SHAFT, FUEL PUMP DRIVE
3171109	SUPPORT, ACCESSORY DRIVE
3171110	SUPPORT, ACCESSORY DRIVE
3410367	TEE, MALE RUN
3410368	TEE, MALE UNION
3638640	PULLEY, IDLER ASSEMBLY
4016278	UNION, MALE
4016280	ELBOW, MALE UNION
4016983	CLUTCH, FAN
4016986	PULLEY, FAN CLUTCH
4066664	HARNESS, ETR CNT MDL WRG
3640341	HEAD, FUEL FILTER
4016127	BRACKET, PUMP
4062159	PUMP, GEAR FUEL
4903527	PUMP, FUEL
3332060	UNION, MALE
4001157	VALVE, CHECK
4000878	VALVE, CHECK
4016420	DISTRIBUTOR, OIL
4086075	BRACKETOIL TUBE

4101118	GASKETOIL PAN ADAPTER
3171565	PAN, OIL
3867743	MODULE, ELECTRONIC CONTROL
3331031	ACTUATOR, ETR FUEL CONTROL
3348442	ACTUATOR, ETR FUEL CONTROL
3634688	UNION, MALE
3638161	ACCESSORIES, ELC SET
3645958	PISTON, ENGINE
4047291	TURBOCHARGER
4039735	COLLAR, THRUST
3598923	SCREW, HEXAGON HEAD SET
4036307	SLINGEROIL
3595589	SHAFT & WHEEL
4038374	HOUSING, TUR BEARING
4037264	BEARING, TUR THRUST
4038464	IMPELLER, TUR COMPRESSOR
4041997	DIFFUSER, TURBOCHARGER
4038175	HOUSING, COMPRESSOR
3591172	HOUSING, TURBINE
193734	SEAL, O RING
4001170	CONNECTOR, MALE
4101022	CONNECTOR, MALE
4086224	MANIFOLD, FUEL
3636409	COVER, AFTERCOOLER
3636412	COVER, AFTERCOOLER
3645973	CLAMPHOSE
4320155	KITWATER PUMP REPAIR
3176512	COVER, PROTECTIVE
3331857	TEE, MALE UNION
4100869	BRACKET, WATER TUBE
3635786	PUMP, WATER
3635712	BODY, WATER PUMP
3646065	GEARIDLER
4975633	COMPRESSOR,2 CYL AIR
4307244BH30	FUEL PUMP
3177040RX	SHAFTSHUTOFF VALVE