



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins QSK19 engine Spare parts catalog

Part number	Description
216484	DIPSTICKBLANK
3081981	Tee, Male Union
3018785	PUMPWATER
3086030	CONNECTIONWATER OUTLET
3202007	SHAFTWATER PUMP
3646200	GUIDE,VALVE STEM
3037536	PLUG,THREADED
4967641	SUPPORT, AIR COMPRESSOR
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
WF2076	WF PKG
4024767	KIT,LINER WITH RINGLINER SEAL 3088298
3347569	CRANKSHAFT, ENGINE
3347937	SEALO RING
3521225	SCREWHEXAGON HEAD SET
3922794	SEAL,O RING
3065698	HOSEPLAIN
3056158	NUT, REGULAR HEXAGON
156810	BREATHER
3076489	THERMOSTAT
3400698	ALTERNATOR
207306	COVEROIL PAN ADAPTER
206996	BELTV RIBBED
107981	CAPFILLER
3634310	HOSE, FLEXIBLE
186780	SEALTHERMOSTAT
3046283	SCREW, HEX FLANGE HEAD CAP
3046200	SPIDER,JAW COUPLING
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
4081176	RING,COMPRESSION PISTON
3081489	SEALOIL
3811995	RODENGINE CONNECTING
2888695	BEARINGTHRUST
S173A	SCREW, HEXAGON HEAD CAP

S181	
S181C	SCREW, HEXAGON HEAD CAP
S194	
S197	
S223	NUT,HEAVY HEXAGON
S224	NUT,HEAVY HEXAGON
S225	
S2286	DRIVE SCREW
S253	NUT,REGULAR HEXAGON JAM
S316	KEY,PLAIN WOODRUFF
S600	WASHER,LOCK
S602	Washer, Plain
S603	WASHER,LOCK
S607	WASHER,LOCK
S608	WASHER,LOCK
S609	WASHER,LOCK
S610	WASHER,LOCK
S622	WASHER,PLAIN
S631	WASHER,PLAIN
S658	
S689	WASHER, PLAIN
S911B	PIPE, PLUG
S923E	DRAINCOCK
S962E	DRAINCOCK
100099	SEAL,RECTANGULAR RING
101264	TUBEOIL FILLER
101626	WASHERPLAIN
105375	NAMEPLATE
108330	WASHER,PLAIN
108604	SCREWHEXAGON HEAD CAP
108707	SCREWHEXAGON HEAD CAP
111445	WASHER,LOCK
118226	SCREW,SOCKET HEAD CAP
124921	DOWEL, PIN
125742	CLAMPT BOLT
127018	WASHER,LOCK
127184	Washer, Plain
127362	WASHER,PLAIN
129069	NUTLOCK
129768	SPRINGVALVE
129839	COVER,SHUTOFF VALVE
129888	SEALRECTANGULAR RING
130083	BEARING, THRUST
130914	WASHERSEALING
132770	BUSHING
135231	PLUG EXPANSION
137872	SCREW,HEXAGON HEAD CAP
139988	SEAL,RECTANGULAR RING
142686	SCREWHEXAGON HEAD CAP
145540	SEALO RING
145623	SEALO RING
151900	SEAL RECTANGULAR RING
153336	BODYFUEL PUMP DAMPER
153338	DAMPER FUEL CONTROL
153518	SEALRECTANGULAR RING
153581	SCREWTWELVE POINT CAP

153582	SCREWTWELVE POINT CAP
158829	SCREW,HEXAGON HEAD CAP
160514	WASHER,PLAIN
166468	CONNECTION, AIR CPR INLET
167157	BALLCHECK
172648	SEAL,RECTANGULAR RING
173086	GASKET,INJECTOR
179901	VALVESHUTOFF
179904	CLAMPHOSE
179931	HOSEPLAIN
3069102	GASKETAIR COMPRESSOR
3521442	SEAL,SPLIT RING
3630125	HOSE,PLAIN
187317	ADAPTERPLAIN
191772	SCREW,TWELVE POINT CAP
196057	DISCVALVE
196421	BRACETUBE
200517	HOSE PLAIN
200861	WASHERPLAIN
3028324	VALVECHECK
201351	CLAMP,WIRE TIE
3063240	HOSE, PLAIN
202897	DIAPHRAGM
203310	WASHERPLAIN
203426	PIN,INJECTOR ROLL
203933	PLUGEXPANSION
204048	PLATECOVER
204476	PLUGEXPANSION
205021	CAPMAIN BEARING
205022	CAPMAIN BEARING
205023	CAPMAIN BEARING
205059	WASHER,PLAIN
205075	CAPMAIN BEARING
205126	WASHERPLAIN
205128	WASHER,PLAIN
205133	BUSHING
205140	BEARINGMAIN STD
205150	BEARINGMAIN STD
205156	BUSHING
205160	BEARINGMAIN STD
205170	BEARINGMAIN STD
205227	PLUG, EXPANSION
205243	IMPELLERWATER PUMP
205247	SEALO RING
205269	RINGRETAINING
205275	SCREWTWELVE POINT CAP
205288	GASKETWTR TRF CONNECTION
205354	SCREWTWELVE POINT CAP
205401	PLUGEXPANSION
205498	PLUGTHREADED
205781	RINGRETAINING
205784	WASHERPLAIN
205840	Bearing, Connecting Rod (Standard)
205898	SEALO RING
206217	STUD
206218	STUD

206224	PLUG,EXPANSION
206256	PLUGTHREADED
206277	GASKET,INTAKE MANIFOLD
206326	SCREW,TWELVE POINT CAP
206343	SUPPORTFRONT ENGINE
206402	SCREW, TWELVE POINT CAP
5566	GEARFLYWHEEL RING
206904	KEY,PLAIN WOODRUFF
206948	SEALOIL
206973	GASKETOIL COOLER CORE
206998	TUBEWATER TRANSFER
207117	GASKETAIR COMPRESSOR
207233	TUBEWATER TRANSFER
207244	SEAL INJECTOR
207252	GEARLUBRICATING OIL PUMP
207256	GEAR,HYDRAULIC PUMP
207378	TUBEWATER TRANSFER
207386	SCREWHEXAGON HEAD CAP
207527	SCREWTWELVE POINT CAP
210029	SCREWTWELVE POINT CAP
212013	HEADFUEL FILTER
43828	CLAMPHOSE
67211	DOWEL, PIN
69324	WASHERPLAIN
69521	BUSHING
69558	DOWELPIN
70624	SEALO RING
70657	COVERACCESS HOLE
70700	SPRINGFUEL PUMP TORQUE
70704	WASHER PLAIN
70760	DOWELPIN
70897	NUT,LOCK
214345	DRAINCOCK
553856	GASKETOIL DRAIN
3000174	HUBSPLINE COUPLING
3000508	TUBEOIL GAUGE
3001305	GASKETCONNECTION
3002201	BELTV RIBBED
3002323	PULLEYALTERNATOR
3002331	PULLEYALTERNATOR
3004686	BUSHING
3004739	GEAR,HYDRAULIC PUMP
3005594	WASHERPLAIN
3006182	SCREWCAPTIVE WASHER CAP
3007380	GASKETHYDRAULIC PUMP
3007632	PLUGEXPANSION
3008400	GASKETHYDRAULIC PUMP
3009620	SPRINGENGINE BARRING
3010595	SCREWCAPTIVE WASHER CAP
3010597	SCREWCAPTIVE WASHER CAP
3010926	GASKETFLANGE
3011076	SEALO RING
3011715	SCREW,CAPTIVE WASHER CAP
3012470	SCREWCAPTIVE WASHER CAP
3012472	SCREWCAPTIVE WASHER CAP
3012474	SCREWCAPTIVE WASHER CAP

3012475	SCREWCAPTIVE WASHER CAP
3012476	SCREWCAPTIVE WASHER CAP
3012478	SCREWCAPTIVE WASHER CAP
3012481	SCREWCAPTIVE WASHER CAP
3013265	SCREWCONNECTING ROD CAP
3014103	WASHER PLAIN
3014449	GASKETFLANGE
3014668	SEALO RING
3014766	SCREW,CAPTIVE WASHER CAP
3015283	SCREWCAPTIVE WASHER CAP
3015525	RINGRETAINING
3017051	SCREW,CAPTIVE WASHER CAP
3018914	GUIDEBARRING SHAFT
3018920	CLAMP,WIRE TIE
3018924	WIRE,GROUND
3019152	GEARENGINE BARRING
3019153	SHAFTBARRING
3019961	NUTPLUG
3021420	SOLENOID,FUEL PUMP
3021735	GASKETFLYWHEEL HOUSING
3025482	SCREW TWELVE POINT CAP
3026556	BEARING, THRUST
3028291	SEAL,O RING
3033038	SCREWCAPTIVE WASHER CAP
3034412	SEAL,O RING
3034721	RETAINERSHAFT
3035026	SEAL,O RING
3035228	SEALO RING
3035624	SCREW, CAPTIVE WASHER CAP
3036666	SEALO RING
3036846	SCREWTWELVE POINT CAP
3037236	SEAL,O RING
3037537	SEAL,O RING
3040814	PLUGTHREADED
3040815	PLUGTHREADED
3040817	SEALO RING
3040818	PLUGTHREADED
3040838	Screw
3040839	SCREWCAPTIVE WASHER CAP
3042328	WASHERPLAIN
3042329	WASHERPLAIN
3042542	SEAL,O RING
3042586	GASKETHAND HOLE
3042590	GASKETOIL PAN
3042619	NIPPLECOUPLING
3042827	SHAFT, WATER PUMP
3042889	SCREWCAPTIVE WASHER CAP
3042890	SCREWCAPTIVE WASHER CAP
3043097	GASKETEXHAUST MANIFOLD
3043909	Bushing, Connecting Rod
3044413	SCREWCAPTIVE WASHER CAP
3045136	WASHERPLAIN
3045137	SCREWHXAGON HEAD CAP
3045986	SEAL,O RING
3046201	SEALO RING
3046202	PLUG,THREADED

3046942	PLUGTHREADED
3047367	BRACKETCRN RESISTOR
3049119	ELBOWMALE UNION
3052061	SCREWHXAGON HEAD CAP
156075	PLUGEXPANSION
156676	RINGRETAINING
188040	BEARINGTHRUST
199358	SLEEVESPLINE COUPLING
204163	HEADCORROSION RESISTOR
205141	BEARINGMAIN 010
205142	BEARINGMAIN 020
205143	BEARINGMAIN 030
205151	BEARINGMAIN 010
205152	BEARINGMAIN 020
205153	BEARINGMAIN 030
205161	BEARINGMAIN 010
205162	BEARINGMAIN 020
205163	BEARINGMAIN 030
205171	BEARINGMAIN 010
205172	BEARINGMAIN 020
205173	BEARINGMAIN 030
205258	RINGRETAINING
205769	SHAFTHYD PUMP DRIVE
205771	
206031	SCREWTWELVE POINT CAP
206202	NUT
207135	SEAL,RECTANGULAR RING
207251	GER,PMP
207253	
213272	PICKUPMAGNETIC
213273	HARNESSWIRING
2870878	HOSE, FLEXIBLE
3002957	CLAMPRETAINING
3004242	GSK,PMP
3004738	GER,PPG
3006236	SLEEVEWEAR
3006237	SLEEVEWEAR
3007368	SUPPORTHYDRAULIC PUMP
3007391	SUPPORTHYDRAULIC PUMP
3013748	DRIVE,HYDRAULIC PUMP
3014993	BUSHING
3016306	CLAMPV BAND
3018909	BUSHING
3019154	GUIDEBARRING SHAFT
3028252	PINROLL
3028349	SEALO RING
3036096	BRACEWATER PUMP
3040810	
3040816	PLG,THD
3040819	PLG,THD
3040911	PLG,THD
3042543	SEALO RING
3042620	NIPPLE,COUPLING
3044896	COVERPROTECTIVE SHIPPING
3045012	PLUGINJECTOR ORIFICE
3045035	PLUGINJECTOR ORIFICE

3045047	PLUG, INJECTOR ORIFICE
3045782	PLUGTHREADED
3045938	SPACERMOUNTING
3046869	PLG,THD
3046943	SEAL O RING
3048292	CLIP
3050897	PLG,THD
3056003	PLG,THD
3056415	SEALO RING
3056416	PLUGTHREADED
3056787	CLAMP, HOSE
3059308	UNIONMALE
3059831	PLUGDRIVE
3060912	GASKET, CONNECTION
3063166	SEAL,O RING
3063809	CLAMPT BOLT
3064321	SCREW,CAPTIVE WASHER CAP
3064523	RING,RETAINING
3065678	TUBEOIL GAUGE
3065790	GASKETLUB OIL CLR HSG
3065791	GASKETTOR CNV OIL COOLER
3065830	SEALOIL
3066310	SCREWCAPTIVE WASHER CAP
3066323	PLUGTHREADED
3066324	
3066325	PLUGTHREADED
3066914	SEAL,O RING
3066938	SEALO RING
3067259	SEALOIL
3067347	PLG,THD
3067424	PLUG,THREADED
3068533	SCREW, CAPTIVE WASHER CAP
3069604	ELBOWMALE UNION
3069846	COVERHAND HOLE
3070679	SCREWHXAGON HEAD CAP
206808	SEAL,GROMMET
3071085	SEALWATER PUMP
3071225	SCREWCAPTIVE WASHER CAP
3071719	SHIMFUEL PUMP GOVERNOR
3073213	GASKETOIL PAN COVER
2872429	SPACER,SEAL
3076102	SEALO RING
3076174	COVERPROTECTIVE SHIPPING
3076720	PLUGTHREADED
3077771	SCREWSELF TAPPING METAL
3079743	DOWELRING
3079754	GASKETOIL SUC CONNECTION
3079794	SCREWTWELVE POINT CAP
3079883	GASKET,AFT HOUSING
3080223	CAPFUEL PUMP FILTER
3081040	DAMPER, VIBRATION
3081465	SCREWHXAGON HEAD CAP
3081494	SEALO RING
3081507	PLUNGERFILTER HEAD
3081514	BUSHING
3081529	PLUGEXPANSION

3081534	COLLET,VALVE
3081551	SCREW,TWELVE POINT CAP
3081566	SCREWTWELVE POINT CAP
3081620	COVERCAMSHAFT
3081621	GASKETCAMSHAFT COVER
3081626	ADAPTERCRANKSHAFT
3081668	PLUGRETAINER
3081677	BUSHING
3081688	TUBEWATER BYPASS
3081695	SEAL,O RING
3081724	SEALSPLIT RING
3081784	BRACKETFREON COMPRESSOR
3081792	HOUSINGFLYWHEEL
3081824	GASKET,TURBOCHARGER
3081825	CLIP
3081837	SCREWTWELVE POINT CAP
3081877	MANIFOLDFUEL
3081895	GASKETRKR LEVER HOUSING
3081898	GASKETRKR LEVER HOUSING
3081950	UNION,MALE
3081951	ELBOWMALE UNION
3081952	UNIONMALE
3081953	UNIONMALE
3081954	UNIONMALE
3081956	UNIONMALE
3081957	UNIONMALE
3081958	ELBOWMALE UNION
3081996	BRACKETFREON COMPRESSOR
3084713	Seal, Oil
3085185	SENSORTEMPERATURE
3085702	TEEMALE BRANCH
3085709	SEAL,O RING
3085715	SHAFT,CAM FOLLOWER
3085733	CONNECTIONWATER BYPASS
3085736	ADAPTEROIL PAN
3085751	SCREWHEXAGON HEAD CAP
3085752	SCREWHEXAGON HEAD CAP
3085753	SCREWHEXAGON HEAD CAP
3085759	PLUGO RING
3085760	CONNECTIONWATER TRANSFER
3085769	ELBOWMALE UNION
3085821	ELBOW, MALE UNION
3085867	SEALOIL
3085886	WASHERPLAIN
3085891	CONNECTIONWATER INLET
3085955	HOUSINGOIL COOLER
3085972	BUSHING
3085973	BUSHING
3085978	BALLROCKER LEVER
3085980	SOCKETROCKER LEVER
3085989	GASKETLUB OIL PUMP
3086016	UNIONMALE
3086019	ELBOWMALE ADAPTER
3086024	HOSE AS.
3086027	CONNECTIONWATER TRANSFER
3086040	UNN,MAL

3086041	ELBOWMALE ADAPTER
3086051	ELBOWMALE UNION
3086052	ELBOWMALE UNION
3086054	HOSEFLEXIBLE
3086055	HOSEFLEXIBLE
3086056	TUBEFUEL SUPPLY
3086058	TUBEFUEL SUPPLY
3086060	TUBEFUEL SUPPLY
3086062	TUBEFUEL SUPPLY
3086064	TUBEFUEL SUPPLY
3086066	TUBEFUEL SUPPLY
3086068	TUBEFUEL DRAIN
3086070	TUBEFUEL DRAIN
3086072	CLAMPTUBE
3086077	CONNECTIONFUEL BLOCK
3086078	CONNECTIONFUEL BLOCK
3086080	MANIFOLDFUEL
3086120	SEALRECTANGULAR RING
3086121	SCREWROUND HEAD CAP
3086132	SHAFTWATER PUMP
3086144	CLIP
3086177	SUPPORTWATER PUMP
3086192	INSERTVALVE
3086221	SHAFT,LUB OIL PUMP DRIVE
3086230	SUPPORT, ACCESSORY DRIVE
3086234	SEALO RING
3086253	ENDCONTROL ROD
3086259	CONNECTIONWATER INLET
3086275	TUBELUB OIL SUCTION
3086279	SEALDUST
3086291	PLATECLAMPING
3086365	SUPPORTALTERNATOR
4328528	PLUG, SPARK
3088298	RINGLINER SEAL
3089177	SOCKETROCKER LEVER
3089715	SHAFTROCKER LEVER
3090007	SCREWRKR LEVER ADJUSTING
3090009	ROLLERCAM FOLLOWER
3090010	ROLLER,CAM FOLLOWER
2888887	TENSIONER,BELT
3090064	ADAPTERFILTER HEAD
3090067	SKIRT,PISTON
3090126	SEALO RING
3090127	SEALO RING
3090169	HOUSINGTHERMOSTAT
3090170	GASKETTHERMOSTAT HOUSING
3090184	BRACKETCHECK VALVE
3090194	SEAL, DUST
3090240	COUPLINGPLAIN HOSE
3090241	COVERLUB OIL COOLER
3090245	UNIONMALE
3090251	BRACKETLIFTING
3090260	PLATETHRUST BEARING WEAR
3090261	RETAINERGEAR
3090297	SEALOIL
3090299	GASKET,AFTERCOOLER COVER

5483654	GASKET,GEAR COVER PLATE
3090358	BEARINGTHRUST
4371927	ROD,PUSH 4371927
3090433	HOSEFLEXIBLE
3090441	SPRINGVALVE
3090442	AIDSTARTING
3090447	ELBOWFEMALE ADAPTER
3090451	VALVECHECK
3090452	HOSEFLEXIBLE
3090478	VALVECHECK
3090495	COVERVALVE
3090758	FLYWHEEL
3090769	SCREEN, FILTER
3090992	VALVECHECK
3096212	HOSEFLEXIBLE
3096260	SEAL,RECTANGULAR RING
3103409	COMPRESSOR2 CYL AIR
3096317	TUBEOIL GAUGE
3096323	SPRINGCOMPRESSION
3096324	PLUNGERPRS REGULATOR
3096326	PUMPLUBRICATING OIL
3096328	COVERLUB OIL PUMP
3096430	BAFFLEBREATHER
3096431	NUTSPRING
3096458	BEARINGTHRUST
3096465	COVERVALVE
3160923	ADAPTEROIL PAN
3099408	SEALO RING
4334080	GASKET,CYLINDER HEAD
3171156	HOSEELBOW
3175846	ELBOWMALE UNION
3200287	SEALKEYWAY
3200405	TUBEFUEL SUPPLY
3200425	TUBEFUEL DRAIN
3200762	TUBECPR WATER OUTLET
3200772	WASHERPLAIN
3200781	PLUG, DRAIN
3200943	SHAFTHYD PUMP DRIVE
3200968	PLUGTHREADED
3201056	COVERFLYWHEEL HOUSING
3201060	COVERHAND HOLE
3201125	SEALO RING
3201128	NUT,REGULAR HEXAGON
3201188	LINK,ADJUSTING
3201251	TUBEAIR FUEL CONTROL
3201287	CLIP
3201388	GASKETFLANGE
3201583	PLUG,THREADED
3201585	SEALO RING
3410171	GSK,SPT
3201737	TUBEFUEL DRAIN
3201759	SCREWHEXAGON HEAD CAP
3202101	PLUGTHREADED
3202114	SHAFT, IDLER
3202117	GASKETCONNECTION
3202162	WIREGROUND

3202283	GASKETWATER PUMP
3278093	PLUGPIPE
3318853	OIL FILTER
FS1000	
3329533	GEAR,CAMSHAFT
3329561	SUPPORTPIVOT SHAFT
3330159	SEALO RING
3330202	SEALO RING
3330600	ACTUATOR,ETR FUEL CONTROL
3330601	ACTUATORETR FUEL CONTROL
3331586	CRANKSHAFTENGINE
3331630	BOSS
3331632	PLATEGEAR COVER
3331695	PANOIL
3331752	RETAINER,VALVE SPRING
3331760	BRACKETWIRING RETAINER
3331774	HARNESSETR CNT MDL WRG
3331775	HARNESSETR CNT MDL WRG
3347638	COVERPROTECTIVE SHIPPING
3347938	SEALO RING
3347939	SEALO RING
3348004	SCREENFILTER
3348515	PINROLL
3348550	VALVEPRESSURE REGULATOR
3348618	SEALD RING
3348703	SEALO RING
3348739	SCREWSOCKET HEAD CAP
3402171	SHAFTIDLER
3402243	HOSEFLEXIBLE
3408213	COVERCAMSHAFT
3408216	SCREWCAPTIVE WASHER CAP
3408227	HOSEPLAIN
3408232	SUPPORTTHM HOUSING
3408249	PLATETHRUST BEARING WEAR
3408259	RODPUSH
3408282	SEAL VALVE STEM
3408296	LEVER,CAM FOLLOWER
3408515	SENSORPRESSURE
3408517	SENSORPRESSURE
3408519	SENSORPRESSURE
3417079	VALVEETR CNT PRESSURE
3417104	SCREWSOCKET HEAD CAP
3417166	VALVECHECK
3417238	SEALO RING
3502449	SEAL,RECTANGULAR RING
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519535	NUTLOCK
3519641	RINGRETAINING
3522597	PINROLL
3522904	LOCKPLATE
3523412	SEALSPLIT RING
3523980	SLINGEROIL
3524418	SHIM
3524419	BAFFLEOIL
3527619	DATAPLATE

3534405	SEAL,RECTANGULAR RING
3536155	WHEELTURBOCHARGER
3536588	SHIELDTURBOCHARGER HEAT
3537301	RINGRETAINING
3537575	HOUSINGTURBINE
3537916	BAFFLETURBOCHARGER NOISE
3590386	CLAMPV BAND
3590435	SCREWSOCKET HEAD CAP
3590444	NUTLOCK
3590445	SPACERMOUNTING
3591522	COLLARTHURST
3591532	BEARINGTUR THRUST
3627372	WASHERPLAIN
3627868	BARREL&PLUNGER
3628411	COVERSTARTER FLANGE
3633971	CLAMPT BOLT
3635250	PINGROOVE
3654215	COVERPROTECTIVE
3658821	HARNESSETR CNT MDL WRG
3678606	SEAL,O RING
3678611	PLUGTHREADED
3678925	SEAL,O RING
3680057	NUTREGULAR HEXAGON JAM
3803153	KITWP REPAIR MAJOR
3803477	KITSEAL
3804667	SETUPPER ENGINE GASKET
4352583	SET,SINGLE HEAD GASKET
3804703	KIT,FRONT CRANKSHAFT SEAL
3804997	SHAFTACCESSORY DRIVE
3804999	SHAFTACCESSORY DRIVE
3811993	TUBELUB OIL TRANSFER
3865312	SENSORTEMPERATURE
3865323	
3865398	SEALO RING
3867147	SCREWTWELVE POINT CAP
3867393	SCREENFILTER
3867640	SEALO RING
3867651	SEALO RING
4307148	SEAL,INJECTOR
3867715	BODYCONTROL VALVE
3867737	VALVEPRESSURE RELIEF
3867742	RETAINERINJECTOR LINK
3914868	PLATECOVER
3929751	GASKETACC DRIVE COVER
4000436	GASKETLUB OIL FIL COVER
4000504	SEALRECTANGULAR RING
4000521	SCREWHEX FLANGE HEAD CAP
4000595	GASKETOIL PAN ADAPTER
4009241	HEADLUB OIL FILTER
4009242	HEADLUB OIL FILTER
4009596	BRACKETRETAINING BRACE
4009598	BRACKETRETAINING BRACE
4009692	SCREENFILTER
4009905	MANUFACTURED) PUMP, FUEL HPI COMPACT 4009905RX
4010577	SEALO RING
4024768	KITLINER

4951905	CONNECTIONWATER TRANSFER
4057874	TUBEAIR
4065627	PLUGDRIVE
4065630	LEVERROCKER
4065633	LEVERROCKER
4065636	LEVERROCKER
4065748	LEVER,CAM FOLLOWER
4067667	CAMSHAFT
4067706	BRACETUBE
4076567	LINKINJECTOR PLUNGER
4080829	GASKETGEAR COVER
4080916	COVERVALVE
4080938	CONNECTIONAIR TRANSFER
4080939	BRACECONNECTION
4081239	MOTORSTARTING
4086649	ROTAROR,VALVE
4088274	DISCACTUATOR
4088863	HOUSINGACTUATOR
4089238	KIT,AC GST/SAL 855MM SGLE
4089717	SETLOWER ENGINE GASKET
4094838	HOSEFLEXIBLE
4094999	TUBEWATER OUTLET
4095010	PINPISTON
4095096	
4098953	MANIFOLDEXHAUST
4098955	MANIFOLDEXHAUST
43828A	CLAMP,HOSE
4902720	SENSOR,PRESSURE
4910190	GASKETCAMSHAFT COVER
4910302	LOCKPLATE
4910518	SEALRECTANGULAR STRIP
4921411	MODULE,ELECTRONIC CONTROL
4922181	GASKET,VALVE COVER
4922207	
4922210	CONNECTION,WATER OUTLET
4922215	SCREW,HEXAGON HEAD CAP
4922291	HOUSING,ROCKER LEVER
4922336	TUBE,WATER OUTLET
4924948	WIRE, SPARK PLUG
4953300	PULLEY, ALTERNATOR
4953332	GEAR, ACCESSORY DRIVE
4953512	SCREW,CAPTIVE WASHER CAP
4953513	SCREW,CAPTIVE WASHER CAP
4953514	MANIFOLD,AIR INTAKE
4953597	DATAPLATE
4970037	HOSE,PLAIN
4986319	DRIVE,ACCESSORY
70183	RINGRETAINING
AR70577	PDC Kit
AS16020	
S103	BOLT
S103A	SCREW,HEXAGON HEAD CAP
S106	SCREW,HEXAGON HEAD CAP
S107	
S109	SCREW,HEXAGON HEAD CAP
S113	

S114	
S119	SCREW,HEXAGON HEAD CAP
S127C	Screw, Hexagon Head Cap
S141	
S144	
S145	SCREW,HEXAGON HEAD CAP
S16002	BEARING, BALL
S16069	BEARING, BALL
3043556	PLUG, THREADED
3071643	SEAL, OIL
3085198	SENSOR, TEMPERATURE
3678605	PLUG, THREADED
S169A	SCREW,HEXAGON HEAD CAP
S166B	SCREW, HEXAGON HEAD CAP
3036665	PLUG, THREADED
S102D	SCREW,HEXAGON HEAD CAP
3201187	LINK, ADJUSTING
3018910	BEARING, THRUST
3018911	PIN, ROLL
3201656	BRACKET, SHIPPING
3811994	ROD, ENGINE CONNECTING
3826824	DECAL
3201185	BOLT, EYE
3201186	BOLT, EYE
3086447	FLYWHEEL
S116A	SCREW, HEXAGON HEAD CAP
3067370	HOSE, PLAIN
3804705	KIT,SEAL
3331672	GASKET, CAMSHAFT
3090391	TOOL, SEAL INSTALLATION
3090392	SCREWHEXAGON HEAD CAP
3096361	DOWEL, PIN
3804704	REAR CRANK SEAL KIT
3090393	TOOL, SEAL INSTALLATION
3096479	SEAL, OIL
3090395	TOOL, SEAL INSTALLATION
3096480	SEAL, OIL
3086127	PULLEY, ACCESSORY DRIVE
4917433	BLOCK, CYLINDER
4917432	BLOCK, CYLINDER
3090258	GEAR, IDLER
3090256	BUSHING
3090257	GEAR, IDLER
3090488	GEAR, IDLER
3402169	SHAFT, IDLER
3402170	DOWEL, RING
3408295	LEVER, CAM FOLLOWER TLA
3408266	LEVER, CAM FOLLOWER
4065751	PIN, CAM FOLLOWER ROLLER
4006772	SOCKET, CAM FOLLOWER
4065747	LEVER, CAM FOLLOWER
4065750	PIN, CAM FOLLOWER ROLLER
3085710	SHAFT, CAM FOLLOWER
4953166	GEAR, CRANKSHAFT
3331631	PLATE, GEAR COVER
3066322	PLUG, THREADED

3100534	UNION, MALE
3085827	UNION, MALE
3103408	COMPRESSOR, AIR
4089207	KIT, HEAD ASSEMBLY
3086131	DRIVE, ACCESSORY TLA
3086122	SHAFT, ACCESSORY DRIVE
3085822	ELBOW, MALE UNION
4922217	KIT, SEAL 4089902
4920028	SEAL, INSTALLED
3080217	RINGRETAINING
3085830	UNION, MALE
3867410	VALVE, CHECK
3160538	SENSOR, PRESSURE
3160539	SENSOR, PRESSURE
3331029	ACTUATOR, ETR FUEL CONTROL
3348498	PUMP, GEAR FUEL
3080195	RING, RETAINING
3330764	SEAL, O RING
3347806	DOWEL, RING
3348054	HOUSING, FUEL PUMP GEAR
3348338	COVER, FUEL PUMP GEAR
3348378	COVER, FUEL PUMP GEAR
3348499	ADAPTER, FUEL CONNECTOR
3417162	SHAFT, IDLER
3867124	PIN, STRAIGHT
3867578	GEAR, FUEL PUMPING
4001717	SHAFT, FUEL PUMP DRIVE
3348500	HUB, JAW COUPLING
3348501	PLATE, COVER
3348503	SUPPORT, FUEL PUMP
3330549	SUPPORT, FUEL PUMP
3348549	VALVE, PRESSURE REGULATOR
3417165	VALVE, CHECK
3329676	VALVE, PRESSURE RELIEF
4001749	VALVE, PRESSURE REGULATOR
3867668	SPRING, VALVE
4001750	BARREL, CONTROL VALVE
4001751	PLUNGER, FUL PRS REGULATOR
4067429	FUEL PUMP MTG
3085849	TEE, MALE BRANCH
3085861	ELBOW, MALE UNION
3090327	COVER, GEAR
3090326	COVER, GEAR
3090440	ELBOW, PLAIN UNION
3086007	BODY, LUBRICATING OIL PUMP
3086006	BODY, LUBRICATING OIL PUMP
3329510	GEAR & SHAFT
3096368	GEAR, LUBRICATING OIL PUMP
3329511	GEAR & SHAFTLUB OIL PUMP
3079701	SHAFT, IDLER
3096327	COVER, LUB OIL PUMP
4057590	TAG, INSTRUCTION
3408503	SENSOR, POSITION
3408502	SENSOR, POSITION
3408518	SENSOR, PRESSURE
3408516	SENSOR, PRESSURE

4002041	VALVE, ETR FUEL CONTROL
3085825	UNION, MALE
3085826	UNION, MALE
3085829	UNION, MALE
3408520	SENSOR, PRESSURE
3331030	ACTUATOR, ETR FUEL CONTROL
113759	INSERT, THREADED
3867714	BODY, CONTROL VALVE
3613253	PLUG, CAVITY
3613536	COVER, PROTECTIVE
3613537	COVER, PROTECTIVE
3621305	CONNECTOR, ELECTRICAL
3658927	HARNESS, ETR CNT MDL WRG
3658928	HARNESS, ETR CNT MDL WRG
3081876	MANIFOLD, FUEL
S170C	SCREW, SOCKET HEAD CAP
3086079	MANIFOLD, FUEL
4089297	TURBOCHARGER KIT
3599007	TURBOCHARGER
3598528	BEARINGTURBOCHARGER
3590377	SCREW,SOCKET HEAD CAP
3590516	DIFFUSER, TURBOCHARGER
3536589	HOUSING, TUR BEARING
3590545	HOUSING, COMPRESSOR
3596532	IMPELLER, TUR COMPRESSOR
3804571	SET, PISTON RING
4081151	KIT, ENGINE PISTON
4081149	PISTON, ENGINE TLA
4081150	TOP, PISTON
3085962	SPRING, VALVE
3090469	VALVE, EXHAUST
4080913	HEAD, CYLINDER
3331730	HEAD, CYLINDER
3331731	HEAD, CYLINDER
3331732	HEAD, CYLINDER
4016438	VALVE, INTAKE
4087890	INJECTOR
3330087	SLEEVE, INJECTOR
3347828	SPRING, INJECTOR
3348527	SPRING, INJECTOR
3417290	SPRING, INJECTOR
4002127	PIN, ROLL
3348547	PLUNGER, INJECTOR TIMING
4002138	PLUNGER, INJECTOR
3348523	PLUNGER, INJECTOR
4002137	COUPLING, INJECTOR PLUNGER
3867424	SOCKET, INJECTOR COUPLING
4002136	COUPLING, INJECTOR PLUNGER
4009787	BARREL, INJECTOR
4076528	HOUSING, TOP STOP SPRING
3348552	LINK, INJECTOR PLUNGER
4087878	NOZZLE & PLUNGER
3076068	BALL, CHECK
3329999	RETAINER, INJECTOR NOZZLE
4010578	HOUSING, INJECTOR SPRING
4087877	NOZZLE, INJECTOR

4903205	PLUNGER, INJECTOR
3085964	CROSSHEAD, VALVE
4065640	LEVER, ROCKER TLA
3089716	SHAFT, ROCKER LEVER
4065629	LEVER, ROCKER
4065632	LEVER, ROCKER
4065635	LEVER, ROCKER
3006315	BRACKET, SHIPPING
3090332	UNION, MALE
3331553	SUPPORT, THM HOUSING
3086290	CONNECTION, TUR OIL DRAIN
3096429	COVER, VALVE
3329524	SHAFT, WATER PUMP
3086123	SHAFT, WATER PUMP
4081090	BODYWATER PUMP
145528	SEAL,O RING
3034572	PICKUP,MAGNETIC
3046286	SPACER,MOUNTING
4953334	GER,PMP
144372	CONNECTIONWATER TRANSFER
3175687	TUBEVENT
3014304	SEAL,RECTANGULAR RING
3086193	INSERT,VALVE
3076130RX	INJECTOR