



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins KTA50 engine Spare parts catalog

Part number	Description
2897691	SWITCH,PRESSURE
3417958	COMPRESSOR, AIR
3010247	COV,VLV
3177713	HOUSING,ROCKER LEVER
AK4040SS	HOSE,FLEXIBLE
2867067	HOSEFLEXIBLE
3643960	SEAL,OIL
3633046	SEALFERRULE
3643961	SHAFTWATER PUMP
4089500	SET PISTONE RING
3037536	PLUG,THREADED
100478	SEALO RING
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
4327234	SENSOR,ENGINE POSITION
3016792	SEAL,OIL 3016792
4098998NX	CRANKSHAFT,ENGINE (rem)
118346	UNIONMALE
3053478	LEVER,ROCKER
3053476	LEVER,ROCKER
3053477	LEVERROCKER
3630839	GASKET,RKR LEVER HOUSING
3062676	SEAL,OIL
193736	SEAL,INJECTOR O RING
3521225	SCREWHEXAGON HEAD SET
3008706	SCREENINJECTOR FILTER
3803528	VALVEEXHAUST
3803518	VALVEINTAKE

3922794	SEAL,O RING
3076125	BARREL & PLUNGER,STEPPED
3076489	THERMOSTAT
3400698	ALTERNATOR
212161	ORING
4024809	KIT,FUEL SOLENOID 4024809
175830	PLUGEXPANSION
3046200	SPIDER,JAW COUPLING
3640775	SEALTAMPER PROOF
FS1006	FUIL WATER (original) FS1006
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
4081176	RING,COMPRESSION PISTON
3081489	SEALOIL
3635074	CORE, COOLER
3642503	LEVER,CAM FOLLOWER 3081413
3078218	SHAFT,CAM FOLLOWER
S169	SCREW,HEXAGON HEAD CAP
S172B	SCREW,HEXAGON HEAD CAP
S174	
S181	
S181B	SCREW,HEXAGON HEAD CAP
S181C	SCREW, HEXAGON HEAD CAP
S186	
S189C	SCREW,SOCKET HEAD CAP
S197	
S199	
S199A	Hexagon Head Cap Screw
S199B	Screw, Hexagon Head Cap
S212	NUT,REGULAR HEXAGON
S213A	NUT,REGULAR HEXAGON JAM
S217	NUT,HEAVY HEXAGON
S2268	FITTING,GREASE
S2286	DRIVE SCREW
S249	NUT,REGULAR HEXAGON JAM
S306	
S316	KEY,PLAIN WOODRUFF
S600	WASHER,LOCK
S602	Washer, Plain
S603	WASHER,LOCK
S607	WASHER,LOCK
S608	WASHER,LOCK
S610	WASHER,LOCK
S611	WASHER,LOCK
S613	

S622	WASHER,PLAIN
S626	WASHER
S640	WASHER
S915A	PLUG,PIPE
S955	BUSHING,REDUCING PIPE
S962E	DRAINCOCK
100099	SEAL,RECTANGULAR RING
100133	SHAFTFUEL PUMP
100216	SHAFTFUEL PUMP DRIVE
102020	SCREW,HEXAGON HEAD CAP
103009	SCREW,HEXAGON HEAD CAP
103023	SCREW,HEXAGON HEAD CAP
103089	WASHER,PLAIN
103266	
103701	CONNECTIONAIR CPR INLET
105375	NAMEPLATE
105503	CONNECTOR,MALE
106069	SCREW,HEXAGON HEAD CAP
107460	CLIP
107695	PINROLL
107948	DOWELDIAMOND
108172	SEAL,O RING
108330	WASHER,PLAIN
108602	SCREW,HEXAGON HEAD CAP
108604	SCREWHEXAGON HEAD CAP
108707	SCREWHEXAGON HEAD CAP
108767	SCREW,HEXAGON HEAD CAP
109319	LOCKPLATE
109917	SCREWSOCKET SET
110266	SCREW,HEXAGON HEAD CAP
110665	
110855	GASKETFUEL PUMP
111445	WASHER,LOCK
112105	ELBOWMALE ADAPTER
114307	BRACE,TUBE
116391	BUSHING
118226	SCREW,SOCKET HEAD CAP
127018	WASHER,LOCK
127316	WASHERPLAIN
127362	WASHER,PLAIN
127454	WASHERPLAIN
127571	WASHER,PLAIN
129768	SPRINGVALVE
129838	KNOB
129839	COVER,SHUTOFF VALVE

129888	SEALRECTANGULAR RING
130083	BEARING, THRUST
131026	SEALO RING
131584	PIN,ROLL
135144	CLAMPT BOLT
135783	WASHER,LOCK
136574	SCREWHEXAGON HEAD CAP
138912	DOWEL,PIN
139473	PLUG,THREADED
139988	SEAL,RECTANGULAR RING
139990	WASHERPLAIN
145507	SEAL,O RING
145529	SEALO RING
145530	SEALO RING
145536	SEAL, O RING
145550	SEALO RING
145581	SEALO RING
145586	SEALO RING
145600	SEAL,O RING 4998542
145613	SEALO RING
146160	WASHERPLAIN
148582	DOWELPIN
149274	HOSEPLAIN
149437	CLAMPT BOLT
151355	LOCKPLATE
151900	SEAL RECTANGULAR RING
153336	BODYFUEL PUMP DAMPER
153338	DAMPER FUEL CONTROL
153581	SCREWTWELVE POINT CAP
154087	SEAL,RECTANGULAR RING
158250	SCREW,TWELVE POINT CAP
158829	SCREW,HEXAGON HEAD CAP
160514	WASHER,PLAIN
163086	PLUG,PIPE
163944	BUSHING
167157	BALLCHECK
168306	SCREW,SLOTTED SET
169834	CLIP
170942	GEARFUEL PUMPING
173086	GASKET,INJECTOR
174299	RETAINERINJECTOR FIL SCN
178079	VALVE, CHECK
179832	SPRINGCOMPRESSION
3053772	PLUNGER, TAPPET
180371	CLIP

3018210	Set, Main Bearing (Standard)
3034245	PUMPFUEL GEAR
181461	GOVERNORAIR COMPRESSOR
3042713	CUPINJECTOR
181466	WASHER,LOCK
3048182	SEAL,O RING
3069102	GASKETAIR COMPRESSOR
3175255	GEAR,CRANKSHAFT
3521034	WHEEL, TURBOCHARGER
3521442	SEAL,SPLIT RING
185804	SCREWHEXAGON HEAD CAP
190397	SLEEVEWEAR
191772	SCREW,TWELVE POINT CAP
193838	SCREW,HEXAGON HEAD CAP
194037	SOCKETROCKER LEVER
196057	DISCVALVE
197032	SCREWHEXAGON HEAD CAP
199919	SCREWTWELVE POINT CAP
69911A	CLIP
S1047A	ELBOW, HOSE
200845	INSERTTHREADED
205230	BUSHING
3007525	KIT LINER 3007525
201048	GASKETCONNECTION
201049	GASKET,CONNECTION
3047390	BEARING,CON ROD (STD)
202897	DIAPHRAGM
203426	PIN,INJECTOR ROLL
203760	WASHER,PLAIN
203933	PLUGEXPANSION
204994	CONNECTORMALE
205059	WASHER,PLAIN
205091	COLLETVALVE
205094	RETAINERVERVALVE SPRING
205126	WASHERPLAIN
205128	WASHER,PLAIN
205129	DOWEL,RING
205227	PLUG, EXPANSION
205269	RINGRETAINING
3177556	SEALRECTANGULAR RING
3201793	DIPSTICK
3626715	COREAFTERCOOLER
205375	SCREWTWELVE POINT CAP
205377	SCREWTWELVE POINT CAP
205393	SCREW,TWELVE POINT CAP

205394	SCREW,TWELVE POINT CAP
205401	PLUGEXPANSION
3818267	HOSEPLAIN
205438	LOCKWIRE
205439	RING,RETAINING
205565	SCREWTWELVE POINT CAP
205571	GASKETOIL SLINGER
205584	SCREWTWELVE POINT CAP
205683	BUSHING
205684	BRACKETLIFTING
205976	RING,RETAINING
206028	SCREW,SOCKET HEAD CAP
206041	SCREWTWELVE POINT CAP
206090	RINGRETAINING
206091	GEARENGINE BARRING
206093	HOUSINGENGINE BARRING
206158	COVER,HYD PUMP FLANGE
206193	GASKETWATER PUMP
206195	SLEEVE,SPLINE COUPLING
206196	RINGRETAINING
206224	PLUG,EXPANSION
206277	GASKET,INTAKE MANIFOLD
206279	GASKETCONNECTION
206326	SCREW,TWELVE POINT CAP
206402	SCREW, TWELVE POINT CAP
206406	COVER,HYD PUMP FLANGE
206407	GASKET,HAND HOLE
206416	GASKETSUPPORT
206443	GASKETTHERMOSTAT HOUSING
206460	GASKETCONNECTION
206526	POINTER,TIMING
206527	SCREW,TWELVE POINT CAP
206576	GASKETTURBOCHARGER
206580	BEARINGMAIN STD
206587	CAPMAIN BEARING
206588	CAPMAIN BEARING
206590	BEARINGMAIN STD
206600	BEARINGMAIN STD
206610	BEARINGMAIN STD
206668	ELBOWPLAIN STREET PIPE
206709	TUBEWATER TRANSFER
206742	PLUG,EXPANSION
206747	GEAR,CAMSHAFT
8265	WASHER,PLAIN
8306	PINROLL

207226	BUSHING
207244	SEAL INJECTOR
207344	BUSHING
207373	COVER,CAMSHAFT
207509	SLEEVE
207515	GASKETCONNECTION
207603	PLATECOVER
208084	RIVET
209773	CLAMP,HOSE
212601	SHAFT,FUEL PUMP DRIVE
212604	RINGRETAINING
212605	GEAR,FUEL PUMPING
43764	CONNECTORMALE
43765	ELBOWMALE ADAPTER
60985	HOSE,PLAIN
63223	HOSE,PLAIN
63842	WASHERPLAIN
67622	PLUGPIPE
67684	WASHER,PLAIN
67946	WASHER,PLAIN
68139	ELBOW,PLAIN ADAPTER
68171	PINROLL
68189	CLIP
68193	PLUGPIPE
68908	LOCKPLATE
69465	CLIP
69519	DOWELPIN
69558	DOWELPIN
69771	SCREW,SOCKET HEAD CAP
70262	WASHER,LOCK
70310	SCREW,PAN HEAD CAP
70415	SEAL,O RING
70662	DOWELPIN
70700	SPRINGFUEL PUMP TORQUE
70704	WASHER PLAIN
70791	SCREWSOCKET HEAD CAP
70897	NUT,LOCK
212613	HUB,JAW COUPLING
212639	ADAPTER,SPLINE
212668	KEYSQUARE
213559	SOCKET,CAM FOLLOWER
215921	COUPLINGPLAIN HOSE
218792	SPACERFAN PILOT
219153	BOLTCONNECTING ROD
650826	PLUNGERFUEL CONTROL

3000082	WASHER,PLAIN
3000138	SUPPORTBEARING
3000139	BEARINGTHRUST
3000174	HUBSPLINE COUPLING
3000204	WASHERSEALING
3000632	GASKET,CONNECTION
3001340	SEALO RING
3001707	SHIM
3001811	SCREW,HEXAGON HEAD CAP
3002956	TUBEWATER TRANSFER
3002993	DOWEL,RING
3003156	SEAL,WIRE
3003354	BEARINGROLLER
3004057	NUTLOCK
3004683	GEAR,IDLER
3004686	BUSHING
3007971	BEARING,CAMSHAFT THRUST
3008465	PLUGPIPE
3008469	PLUGPIPE
3009475	SHAFTPIVOT
3009477	SLEEVE
3009481	SHAFTIDLER
3009482	BRACKETIDLER PULLEY
3010410	COVERACCESS HOLE
3010595	SCREWCAPTIVE WASHER CAP
3011076	SEALO RING
3011580	GASKETAFTERCOOLER COVER
3011715	SCREW,CAPTIVE WASHER CAP
3011884	INSERTLINER
3012281	BRACKETFAN
3013036	SHAFTSHUTOFF VALVE
3013266	SCREWCONNECTING ROD CAP
3013811	DIAPHRAGM
3014103	WASHER PLAIN
3014449	GASKETFLANGE
3014575	CAPFUEL PUMP FILTER
3014668	SEALO RING
3014766	SCREW,CAPTIVE WASHER CAP
3016825	ROLLERCAM FOLLOWER
3016826	ROLLERCAM FOLLOWER
3017051	SCREW,CAPTIVE WASHER CAP
3017961	RODPUSH
3018655	SPRINGCOMPRESSION
3018761	PULLEY,ACCESSORY DRIVE
3018920	CLAMP,WIRE TIE

3021123	SEALO RING
3021470	SCREWCAPTIVE WASHER CAP
3021618	PLUNGERPRS REGULATOR
3021977	COVERSPRING PACK
3023066	SEAL,O RING
3023217	PLUG,THREADED
3023499	CAPIDLER LEVER
3023536	SCREWHEXAGON HEAD CAP
3025485	WASHERPLAIN
3026312	SHIM
3026313	SHIM
3026423	GASKETAFTERCOOLER COVER
3026426	GASKETFLANGE
3026556	BEARING, THRUST
3026557	BEARINGTHRUST
3027728	SPACERMOUNTING
3028291	SEAL,O RING
3028372	ASSEMBLYSHAFT & SPROCKET
3028552	BODYBYPASS VALVE
3029631	CLAMP, V BAND
3030207	RETAINER,DIPSTICK
3030792	HOSE, HUMP
3032627	UNION,MALE
3032628	ELBOW,MALE UNION
3032633	SCREW,TWELVE POINT CAP
3033405	HEAD,LUB OIL FILTER
3033626	WASHERPLAIN
3033629	PIN,ROLL
3033719	DOWELRING
3033740	VALVECHECK
3033742	PLUGTHREADED
3033800	WASHER,PLAIN
3033853	SHAFTIDLER
3033915	SEAL,O RING
3034408	SEALO RING
3034412	SEAL,O RING
3034451	HOUSINGACTUATOR
3034452	DISC,ACTUATOR
3034574	SCREWHEX FLANGE HEAD CAP
3035083	ISOLATOR,VIBRATION
3035084	ISOLATOR,VIBRATION
3035228	SEALO RING
3035697	SCREWHEXAGON HEAD CAP
3035844	TUBE-FUEL IN
3036115	COVER,PROTECTIVE SHIPPING

3036230	SCREWHEXAGON HEAD CAP
3036460	WASHER,SPRING
3036666	SEALO RING
3036846	SCREWTWELVE POINT CAP
3037236	SEAL,O RING
3037489	MOTOR,AIR STARTING
3037537	SEAL,O RING
3037662	ELBOW,MALE UNION
3037821	GASKET,EXHAUST MANIFOLD
3038743	VALVE, CHECK
3038938	COVER,ROCKER LEVER
3039164	LEVER,CAM FOLLOWER
3040721	GASKETCAM FOL HOUSING
3040722	GASKETCAMSHAFT COVER
3040814	PLUGTHREADED
3040818	PLUGTHREADED
4307427	ADAPTER,INJECTOR
3042427	SPRING,COMPRESSION
3042428	SPRING,COMPRESSION
3042430	RETAINERINJECTOR CUP
3042542	SEAL,O RING
3042770	Fan Idler Assembly
3043032	PIPEEXHAUST OUTLET
3043211	GASKET,OIL PAN
3043213	GASKETOIL PAN
3043909	Bushing, Connecting Rod
3045136	WASHERPLAIN
3045137	SCREWHEXAGON HEAD CAP
3045229	SHAFTACCESSORY DRIVE
3045986	SEAL,O RING
3046201	SEALO RING
3046202	PLUG,THREADED
3046852	GASKET,ACC DRIVE SUPPORT
3047276	PISTONAIR FUEL CONTROL
3047278	PISTONAIR FUEL CONTROL
3047665	GASKET,CONNECTION
3049041	RETAINERSPRING
3050454	IMPELLERWATER PUMP
3050624	VALVEPRESSURE RELIEF
3050944	GASKET,FLANGE
3051461	NUTLOCK
3051463	WASHERPLAIN
3052218	RETAINER,INJECTOR SPRING
3052231	RETAINERINJECTOR LINK
3052233	LINK,INJECTOR PLUNGER

3052860	SPACERMOUNTING
3053201	COVER,AFTERCOOLER
173085	PLUGORIFICE
199358	SLEEVESPLINE COUPLING
204995	ELBOWMALE ADAPTER
205199	SCREWTWELVE POINT CAP
4095009	PIN, PISTON K
205659	SPRINGCOMPRESSION
206092	SPRINGCOMPRESSION
206421	GASKETGEAR HOUSING
206446	GASKET WTR TRANSFER TUBE
207038	SEALO RING
207251	GER,PMP
207253	
207551	SEALO RING
216187	SEAL,O RING
3001719	PINSTRAIGHT
3003016	SEALO RING
3004594	GEAR
3005939	GASKETCOVER PLATE
3005940	GASKETGEAR HOUSING
3007441	SEALO RING
3007512	SEALO RING
3008710	SEALRECTANGULAR RING
3008921	GASKETPRS RLF VALVE BODY
3009323	GSK,COV
3009324	GASKET,WATER HEADER COVER 3637727
3010269	DRIVE ACCESSORY
3628973	GSK,PLT
3016316	VALVECOUPLING
3019416	SPRINGTORSION
3022695	MUFFLER
3022696	LUBRICATORAIR STG MOTOR
3022697	I/R Relay Valve
3023077	NIPPLECOUPLING
3023130	SEALDUST
3026391	SEALRECTANGULAR RING
3026392	SEAL,RECTANGULAR RING
3026421	SEALO RING
3026796	ELBOWPLAIN STREET PIPE
3026802	BRACESTARTING MOTOR
3026925	CONNECTIONOIL TRANSFER
3026926	SPRINGCOMPRESSION
3026927	PLUNGERPRS REGULATOR
3027988	RINGRETAINING

3028409	PULLEYIDLER
3028696	COVER,OIL PAN :3178743
3029301	NUTLOCK
3029684	GEAR & SHAFTLUB OIL PUMP
3029687	GEAR & SHAFT,LUB OIL PUMP
3029700	BUSHING
3029701	RETAINERSHAFT
3029702	BEARINGTHRUST
3029708	SHAFTIDLER
3029857	PINROLL
3030487	SPACERBEARING
3030518	SCREWHEX FLANGE HEAD CAP
3030990	RODCONTROL
3030991	ENDCONTROL ROD
3030992	ENDCONTROL ROD
3030993	NUTREGULAR HEXAGON JAM
3031385	VALVE,PRESSURE RELIEF
3031470	RODCONTROL
3031544	SEAL,RECTANGULAR RING
3031989	CLAMP,TUBE
3031998	BRACKET,OIL TUBE
3032629	PLUG,THREADED
3035001	TUBE,LUB OIL TRANSFER
3040710	TUBE,WATER TRANSFER
3040810	
3040819	PLG,THD
3040911	PLG,THD
3042750	PULLEYIDLER
3043214	GASKET,OIL PAN
3043642	WASHERSPRING
3044613	VALVEAIR STARTER
3044993	PLUGINJECTOR ORIFICE
3045047	PLUG, INJECTOR ORIFICE
3046287	SPACERMOUNTING
3046943	SEAL O RING
3047924	SCREW,HEXAGON HEAD SET
3050945	CONNECTIONWATER INLET
3051069	SPRINGCOMPRESSION
3051752	COVERFUEL PUMP
3053502	BARREL, INJECTOR
3054411	SPRINGLEAF
3054852	SPRINGCOMPRESSION
3055069	PLUG,THREADED
3056356	HARNESSWIRING
3057139	RODPUSH

3058867	COVERFUEL CONTROL
3060605	BARREL,PLUNGER,OIL VALVE
3060606	BODYOIL CONTROL VALVE
3060609	VALVE,OIL CONTROL
3062119	BALL,CHECK
4327021	SWITCH,TEMPERATURE
3063019	
3063674	ELBOW,MALE UNION
3064321	SCREW,CAPTIVE WASHER CAP
3065723	SCREW,CAPTIVE WASHER CAP
3065830	SEALOIL
3065944	SCREW,CAPTIVE WASHER CAP
3066497	SCREWHX FLANGE HEAD CAP
3066898	CAMSHAFT
3066899	CAMSHAFT
3066914	SEAL,O RING
3067344	WASHER,PLAIN
3067347	PLG,THD
3067371	HOSE,PLAIN
3067424	PLUG,THREADED
3067884	SCREWSOCKET HEAD CAP
3068528	CLIP
3068859	CAP,TAPPET TOP STOP
3068860	NUTLOCK
3069015	NUTLOCK
3069026	CAP
3069027	COVER,GEAR
3069776	ADAPTER,CRANKSHAFT
3069781	SPACER,CRANKSHAFT
3070108	GASKETBYPASS VALVE BODY
3070186	WASHERPLAIN
3073890	BODYFUEL SHUTOFF VALVE
3073998	DISCVALVE
3074025	MODULE,ELECTRONIC CONTROL
3075381	TAPPET,HYD VAR TIMING
3075526	COVERFUEL PUMP
3076124	
3076132	INJECTOR
3076226	GASKETAIR COMPRESSOR
3076346	SLEEVEWEAR
3077526	BARRELAIR FUEL CONTROL
3079537	BODYFUEL PUMP
3080521	(REMANUFACTURED) AFC CENTRY RH,1,E,P FCBG51R
3081064	HEAD, CYLINDER
3640315	ROTATOR, VALVE

3084539	SEAL,O RING
3084623	MANIFOLDOIL
3084624	MANIFOLDOIL
3084728	HOUSINGACTUATOR
3085345	SOCKET, TAPPET
3086192	INSERTVALVE
3086362	CROSSHEAD,VALVE
3088317	LOCKPLATE
3088371	SEAL,DUST
3088853	PANOIL
3090769	SCREEN, FILTER
3095291	CONNECTOR,MALE
3095292	ELBOWMALE ADAPTER
3096077	GASKETFUEL PUMP
3631246	PISTONENGINE
3096857	VALVESHUTOFF
3098593	HOUSINGFILTER
3098594	FILTERFUEL
3160924	SEALDUST
4334080	GASKET,CYLINDER HEAD
3171368	GASKET,TURBOCHARGER
3175027	WASHER,PLAIN
3175032	GASKETBREATHER
3175056	SPACERMOUNTING
3175058	CLIP
3175074	SCREWHEXAGON HEAD CAP
3175239	NUT,LOCK
3175280	SPACERMOUNTING
3175281	SUPPORTBEARING
3175309	HOSE, FLEXIBLE
3175318	TUBE,LUB OIL DRAIN
3175452	HEADCORROSION RESISTOR
3175453	HEADCORROSION RESISTOR
3175517	GASKETFLANGE
3175573	RINGRETAINING
3175705	SEALFERRULE
3175716	ELBOW,MALE ADAPTER
3175773	ELBOWMALE ADAPTER
3175797	CONNECTIONFUEL BLOCK
3175856	GASKET,HAND HOLE
3175857	SUPPORTWATER PUMP
3176216	WEIGHTCRANKSHAFT COUNTER
3176218	DOWEL,RING
3176355	ELBOWMALE ADAPTER
3176459	BELTV RIBBED

3176465	SCREWHEXAGON HEAD CAP
3176552	SEAL,TAMPER PROOF
3176607	BREATHERCRAKCASE
3176618	DOWEL,DIAMOND
3176710	TUBEFUEL SUPPLY
3176772	SHAFT,ROCKER LEVER
3176857	DOWELRING
3176918	HOUSING GEAR
3177039	TUBE BREATHER
3177040	SHAFTSHUTOFF VALVE
3177045	WASHER,PLAIN
3177108	GASKETFILTER HEAD
3177125	SUPPORTPIVOT SHAFT
3177128	SLEEVEWEAR
3177129	BEARINGTHRUST
3177160	GASKET,GEAR COVER
3177198	ELBOW,MALE UNION
3177300	CONNECTIONADAPTER
3177314	TUBEWATER TRANSFER
3177315	TUBEWATER TRANSFER
3177316	TUBEWATER TRANSFER
3177433	COVER,LUB OIL FILTER
3177443	SCREWHEX FLANGE HEAD CAP
3177509	BUSHING
3177510	BUSHING
3177511	TUBELUB OIL SUCTION
3177513	BRACKETOIL TUBE
3177530	HOSE,PLAIN
3177661	CONNECTIONAIR CROSSOVER
3177662	CONNECTIONAIR CROSSOVER
3177731	TUBEWATER TRANSFER
3177732	TUBEWATER TRANSFER
3177760	SCREWHEXAGON HEAD CAP
3630452	GASKET,TURBOCHARGER
3177945	SCREWHEX FLANGE HEAD CAP
3178044	TUBEWATER TRANSFER
3178076	GASKET,GEAR HOUSING
3178255	TUBEEXHAUST OUTLET
3178290	CONNECTIONWATER TRANSFER
3178319	TUBEWATER BYPASS
3178320	TUBEWATER BYPASS
3178450	SHAFTIDLER
3178457	Washer, Plain
3178462	BRACKETRADIATOR
3178466	CONNECTIONWATER TRANSFER

3178499	CLIP
3178545	TUBEWATER TRANSFER
3178548	TUBEWATER TRANSFER
3178549	TUBEWATER TRANSFER
3178698	FAN,ENGINE
4955242	BLOCKCYLINDER
3178812	COVER,HAND HOLE 3642213
3178947	SCREWHEXAGON HEAD CAP
3179026	GASKETCONNECTION
3179027	GASKETCONNECTION
3179035	GASKET,WTR TRF CONNECTION
3179664	VALVE, PISTON COOLING
3179822	CONNECTORTUBE
3179935	PULLEYALTERNATOR
3179943	PULLEYACCESSORY DRIVE
3200287	SEALKEYWAY
3201125	SEALO RING
3201128	NUT,REGULAR HEXAGON
3201568	PLUGCOUPLING
3201583	PLUG,THREADED
3201585	SEALO RING
3201739	SHAFT,BARRING
3201740	ASSEMBLY,ENGINE BARRING
3202162	WIREGROUND
3202199	HOUSING,ROCKER LEVER
3202210	GUIDEVALVE STEM
3252438	CONNECTORTUBE
3252444	ELBOWTUBE CONNECTOR
3277045	SPRINGCOMPRESSION
3279794	SEALINJECTOR O RING
3279819	LINK,INJECTOR PLUNGER
3279821	SCREWINJECTOR STOP
3279850	NUTTAPPET TOP STOP LOCK
LF3325	CTG,FIL
LF777	LF PKGA
3648162	SEAL, DUST
3348860	SEALFERRULE
3408326	ACTUATORELC GOVERNOR WITH SEAL,O-RING 304816
3408591	SENSOR,PRESSURE
3411695	CLAMPINJECTOR
3417076	PLUG,THREADED
3417077	SCREW,SOCKET HEAD CAP
3417096	SCREW,SOCKET SET
3417098	SCREW,SOCKET HEAD CAP
3502449	SEAL,RECTANGULAR RING

3504967	WASHERPLAIN
3519535	NUTLOCK
3519627	Bearing, Turbocharger
3519641	RINGRETAINING
3522904	LOCKPLATE
3523412	SEALSPLIT RING
3523420	IMPELLERTURBO HC5A
3523980	SLINGEROIL
3524418	SHIM
3524419	BAFFLEOIL
3524421	DIFFUSER, TURBOCHARGER
3525073	SCREWHEXAGON HEAD SET
3525220	HOUSINGCOMPRESSOR HC5A KTA50
3528109	CLAMPV BAND
3529372	NUTREGULAR HEXAGON
3536588	SHIELDTURBOCHARGER HEAT
3536914	BEARINGTUR THRUST
3591522	COLLARTHURST
3594555	Housing, Tur Bearing
3626788	BELTV RIBBED
3626798	BRACKETSOLENOID
3626801	LINKADJUSTING
4380750	NUT,LOCK 4380750
3626859	PULLEYCRANKSHAFT
3626872	TEEMALE ADAPTER
3626873	TEEMALE ADAPTER
3626874	SOLENOID
3626875	SENSOR, TEMPERATURE
3626879	CLUTCH,FAN
3626948	TUBEAIR
3626999	COVERAFTERCOOLER
4376118	PUMP,WATER
3627095	SCREWHEXAGON HEAD CAP
3627309	ADAPTER,FILTER HEAD
3627412	CLIP
3627449	SEALRECTANGULAR RING
3627546	TUBE, CPR WATER OUTLET
3627548	TUBECPR WATER INLET
3627695	SEAL,O RING
3627719	BRACE,WIRING
3627756	BRACKET,AIR CONTROL VALVE
3627763	CLAMPRETAINING
3627786	CONNECTIONADAPTER
3627793	ELBOWPLAIN STREET PIPE
3627799	CONNECTORMALE

3627802	CONNECTORMALE
3627803	CONNECTOR,MALE
3627808	SUPPORTTHM HOUSING
3627834	GEARLUBRICATING OIL PUMP
3627856	CONNECTORMALE
3627912	COVERLUB OIL PUMP
3627927	PLUNGERPRS REGULATOR
3627938	GASKET,COVER PLATE
3627961	SEAL,THERMOSTAT
3627999	SUPPORTALTERNATOR
3628002	BUSHINGREDUCING PIPE
3628003	BUSHINGREDUCING PIPE
3628045	HOUSINGFLYWHEEL
3628078	CONNECTIONWATER INLET
3628160	HOSEFLEXIBLE
3628194	SCREW,HEXAGON HEAD CAP
3628196	SCREW,HEXAGON HEAD CAP
3628229	COVER,HAND HOLE
3628277	GEARLUB OIL PUMPING
3628367	COVERLUB OIL PUMP
3628402	BRACKET,OIL TUBE
3628411	COVERSTARTER FLANGE
3628452	SCREWHEXAGON HEAD CAP
3628476	BRACKETPUMP
3628517	CONNECTIONFUEL BLOCK
3628518	CONNECTIONFUEL BLOCK
3628522	UNIONMALE
3628524	HOSE,FLEXIBLE
3628553	BRACETUBE
3628554	BRACE,TUBE
3628604	PLUG,PIPE
3628605	PLUG,PIPE
3628606	PLUG,PIPE
3628607	PLUG,PIPE
3628608	PLUG,PIPE
3628609	PLUG,PIPE
3628610	PLUGPIPE
3628635	HOSE,PLAIN
3628639	SHAFTWATER PUMP
3628750	SWITCH,PRESSURE
3628798	GEAR,CRANKSHAFT
3628822	GEAR IDLER
3628823	GEAR,IDLER
3628889	HOSEFLEXIBLE
3628894	SEALDUST

3628895	SEALOIL
3628902	WASHER,PLAIN
3628931	TUBEFUEL SUPPLY
3628961	UNION,MALE
3628962	UNION MALE
3628963	ELBOW, MALE UNION
3628965	PRIMERENG LUB OIL SP
3629065	COVERWATER HEADER
3629066	COVER,WATER HEADER 3648236
3629067	SPACER,MOUNTING
4920076	GASKET,ROCKER LEVER COVER
3629141	GASKET,LUB OIL FIL COVER
3629146	CONNECTION,OIL TRANSFER
3629161	HARNESS,ETR CNT MDL WRG
3629373	FLEXPLATE
3629387	GASKETFILTER HEAD
3629408	CONNECTION,FUEL BLOCK
3629409	CONNECTIONFUEL BLOCK
3629410	RETAINERSPRING
3629411	SEATPRS REGULATOR VALVE
3629451	CLIP
3629452	CLIP
3629496	ELBOW,MALE ADAPTER
3629497	DRAINCOCK
3629516	CLIP
3629538	HOUSING,ROCKER LEVER
3629540	TUBE,WATER TRANSFER
3629541	HEADLUB OIL FILTER
3629698	TEE,STREET PIPE
3629855	BUSHING
3629861	CVR,WTR
3629962	WASHER,PLAIN
3630032	MANIFOLDEXHAUST
3630033	MANIFOLDEXHAUST
3630164	PLUG,THREADED
3630505	MANIFOLD, EXHAUST
3630243	MANIFOLDAIR INTAKE
3630244	MANIFOLDAIR INTAKE
3630364	CONNECTIONFUEL BLOCK
3630408	BRACEAIR COMPRESSOR
3630734	TEE,MALE UNION
3630736	ELBOW,MALE UNION
3630740	SEAL,O RING
3630741	HEADFUEL FILTER
3630764	TEEMALE UNION

3630806	ELBOW,MALE UNION
3630864	HOSE, FLEXIBLE
3630865	HOSE,FLEXIBLE
3630867	HOSE, FLEXIBLE
3630874	GASKETFLYWHEEL HOUSING
3630877	CONNECTOR INTAKE
3630969	GASKET,LUB OIL CLR HSG
3631295	HOSE, FLEXIBLE
3631471	ADAPTERO RING
3631690	ELBOWMALE UNION
3632225	ROD,ENGINE CONNECTING
3632336	HOSE, FLEXIBLE
3632337	HOSEFLEXIBLE
3632900	BRACKETSOLENOID
3633045	
3633047	NUTTUBE
3633076	HOSE,PLAIN
3633216	MANIFOLDFUEL
3633217	MANIFOLDFUEL
3633245	TEE,PLAIN ADAPTER
3633246	VALVECHECK
3633331	GEARLUBRICATING OIL PUMP
3633479	NUT,LOCK
3633715	SWITCH,RELAY
3633805	CLAMP,V BAND
3643725	SPRING,VALVE
3633972	CLAMP,T BOLT
3633974	CLP,BOL
3641131	CLAMP,T BOLT
3634007	SEAL,WATER PUMP
3634019	PLUGEXPANSION
3634065	SUPPORT,WATER PUMP
3634172	BRACKETVALVE
3634269	DOWELDIAMOND
3634304	HOSE,FLEXIBLE
3634308	HOSEFLEXIBLE
3634389	HOSEFLEXIBLE
3634390	HOSE, FLEXIBLE
3634395	HOSE, FLEXIBLE
3634396	HOSEFLEXIBLE
3634428	HOSE, FLEXIBLE
3634430	HOSE,FLEXIBLE
3634503	HOSEFLEXIBLE
3634508	HOSE,FLEXIBLE
3634522	HOSE,FLEXIBLE

3634646	BODYLUBRICATING OIL PUMP
3634648	PUMP,LUBRICATING OIL
3634685	UNIONMALE
3634690	UNIONMALE
3634699	UNIONMALE
3635032	HOSEFLEXIBLE
3635033	HOSEFLEXIBLE
3635372	COVER,HAND HOLE
3647025	BODYWATER PUMP
3640685	ADAPTERO RING
3654718	(REMANUFACTURED) MODULE,ELECTRONIC CONTRO
3800731	SETUPPER ENGINE GASKET
3803615	KITSEAL
3803852	KIT,ASSESSORY DRIVE SEAL
3803927	BUSHINGLUBE OIL PUMP
3804300	SETLOWER ENGINE GASKET
3804700	KIT,STC TAPPET REPAIR
3818885	SEAL,O RING
3888312	CHEM. PKG. DCA65-L
4009247	PINCAM FOLLOWER ROLLER
4009248	PINCAM FOLLOWER ROLLER
4016364	DOWELPIN
4017424	HARNESS, WIRING
4017621	PLUG,EXPANSION
4058964	RESISTOR,CORROSION
4066112	SEAL,O RING
4077027	
4080234	CLIP
4098998	CRANKSHAFTENGINE
4101094	LEVERIDLER
43696A	SEAL,O RING
43828C	CLAMP,HOSE
4916693	ADAPTER,FILTER HEAD
4953321	GEAR,CAMSHAFT
650829	SPRINGVALVE
651045	WASHERPLAIN
67184B	INSERTTHREADED
68138	CONNECTOR,MALE
68152A	CLIP
69204D	RINGRETAINING
70183	RINGRETAINING
70772B	SCREWFILLISTER HEAD CAP
AF25708M	
AK4010SS	HOSE,FLEXIBLE
AK4044SS	HOSE,FLEXIBLE

AR12111	*
AS10014SL	HOSE, FLEXIBLE
2865878	HOSE,FLEXIBLE
AS4011SL	HOSE, FLEXIBLE
AS401440SS	HOSE, FLEXIBLE
AS40144SS	HOSE,FLEXIBLE
AS4020SL	HOSE,FLEXIBLE
AS4023SL	HOSE,FLEXIBLE
AS4046SL	HOSE, FLEXIBLE
AS8038SS	HOSE, FLEXIBLE
S1003A	SEAL, GROMMET
S103A	SCREW,HEXAGON HEAD CAP
S103D	SCREW,HEXAGON HEAD CAP
S1042A	TEE,MALE ADAPTER
S109	SCREW,HEXAGON HEAD CAP
S110	SCREWSOCKET HEAD CAP
S112	SCREW,HEXAGON HEAD CAP
S113	
S116	SCREW,HEXAGON HEAD CAP
S117	SCREW,HEXAGON HEAD CAP
S119	SCREW,HEXAGON HEAD CAP
S120	
S123	
S125	SCREW,HEXAGON HEAD CAP
S126	Screw, Hexagon Head Cap
S127	SCREW,HEXAGON HEAD CAP
S134	SCREW,HEXAGON HEAD CAP
S137	SCREW,HEXAGON HEAD CAP
S139	
S140	SCREW,HEXAGON HEAD CAP
S141	
S145	SCREW,HEXAGON HEAD CAP
S153	SCREW,HEXAGON HEAD CAP
S16052	BEARING,BALL
S16054	BEARING, BALL
S16069	BEARING, BALL
S16240	
S163	SCREW, HEX HEAD CAP
S164	SCREW,HEXAGON HEAD CAP
S167B	SCREW,HEXAGON HEAD CAP
S910B	PLUG, PIPE
3800729	SETSINGLE HEAD GASKET
S169A	SCREW,HEXAGON HEAD CAP
S162A	SCREW,HEXAGON HEAD CAP
205069	LEVER, CAM FOLLOWER

3628799	GEAR, IDLER
3631474	SEAL, O RING
3630068	BODY, PISTON COOLING VALVE
3634687	UNION,MALE 3634685
3628720	HOSE, TURBO OIL SUPPLY
3634692	UNION, MALE
3628722	HOSE, TURBO OIL SUPPLY
S907A	PLUG, PIPE
3631805	PLUG, PIPE
3627723	RETAINER, SHAFT
3634066	SUPPORT,WATER PUMP 3634065
3630034	PLUG,THREADED 3023217
3630358	CONNECTION,FUEL BLOCK 3630364
3633212	MANIFOLD, FUEL
3633213	MANIFOLD, FUEL
3628633	ELBOW, MALE ADAPTER
3630765	TEE, PLAIN ADAPTER
3177812	SUPPORT, FRONT ENGINE
S121B	SCREW,HEXAGON HEAD CAP
3627026	COVER, GEAR
4916694	HEAD, FUEL FILTER
3100524	UNION, MALE
S150A	SCREW,HEXAGON HEAD CAP
S167A	SCREW, HEXAGON HEAD CAP
3630681	SEAL, OIL
3073891	BODY, SHUTOFF VALVE
3629545	CONNECTION, AIR CROSSOVER
S170A	SCREW, HEXAGON HEAD CAP
3036665	PLUG, THREADED
3053667	PLUNGER, OIL CONTROL VALVE
3060604	BARREL, OIL CONTROL VALVE
3069989	COVER, OIL CONTROL VALVE
4009927	COVER, DIAPHRAGM
3417103	PLUG, THREADED
3632169	ROD, ENGINE CONNECTING
3027151	NAMEPLATE
3630107	DECAL KIT
3027935	DECAL
3315228	DECAL
3315230	DECAL
3318651	DECAL
3329609	DECAL
3329610	DECAL
3329611	DECAL
3630483	COVER, PROTECTIVE

3630484	COVER, PROTECTIVE
3889382	DECAL
3176521	COVERPROTECTIVE
3166289	GASKET, CYLINDER HEAD
S110B	SCREW, HEXAGON HEAD CAP
3033726	COVER, FUEL PUMP GEAR
3033728	HOUSING, FUEL PUMP GEAR
3009631	COVER, CAMSHAFT
102827	SEAL, O RING
3175861	BRACKET, SHIPPING
S130A	SCREW, HEXAGON HEAD CAP
AR11496	SUPPORT, AND BUSHING
3177278	SUPPORT, ACCESSORY DRIVE
3177279	SUPPORT, ACCESSORY DRIVE
AR11501	HSG,THM & SPT ASSEMBLY
3803338	TURBOCHARGER
3015321	PULLEY, ACCESSORY DRIVE
3178070	DATAPLATE
3178910	BLOCK, CYLINDER
3627300	BUSHING
3628278	GEAR, LUB OIL PUMPING
3029689	GEAR & SHAFT,LUB OIL PUMP 3029687
3029686	GEAR & SHAFT,LUB OIL PUMP 3029684
S152A	SCREW, HEXAGON HEAD CAP
3632938	TURBO, OIL SUPPLY MTG
S684	WASHER, PLAIN
3629424	BRACKET,CONNECTION 3634008,ADAPTER,PLAIN PIPE
3028408	PULLEY, IDLER
3635035	LEVER, IDLER
3077528	ASSEMBLY, AFC
3077525	BARREL, AIR FUEL CONTROL
3074224	PLUNGER, AIR FUEL CONTROL
3098636	DATA, APL CONSTANTS
3160411	CODE, ENGINE CONTROL
3160414	DATA, ELECTRONIC CONSTANTS
3160511	DATA, ENGINE CONTROL
3634693	UNION, MALE
3631691	ELBOW, MALE UNION
3630017	CONNECTION, AIR CROSSOVER
3630507	MANIFOLD, AIR INTAKE
3630508	MANIFOLD, AIR INTAKE
3635804	ADAPTER, OIL PAN
3083727	SENSOR, PRESSURE
3254316	CLAMP, HOSE
3178550	TUBE, WATER TRANSFER

3633179	NUT, TUBE
3631375	CONN, LB OIL CONTROL
3630735	TEE, MALE UNION
3630737	ELBOW, MALE UNION
3630732	UNION MALE 3634699
3630733	UNION, MALE
3631379	CONN,RB OIL CONTROL
3630730	UNION MALE 3634699
3630731	UNION, MALE
3630878	UNION, MALE
3632028	HOSE,FLEXIBLE
3594104	TURBOCHARGER
3534168	HOUSING, TURBINE
3634696	UNION, MALE
3628940	Шкив генератора
S111B	SCREW, HEXAGON HEAD CAP
3100550	UNION, MALE
3100549	UNION, MALE
4023SL	HOSE
3626874RX	SOLENOID
3408591RX	SENSOR, PRESSURE
3628750RX	SWITCH PRESSURE
3408607RX	SWITCH PRESSURE
3079604RX	SENSOR, SPEED
3408631RX	SWITCH, TEMPERATURE
3044613RX	VALVEAIR STARTER
3053476RX	LEVER ROCKER
3086362RX	CROSSHEAD, VALVE
3017961RX	RODPUSH
3037489RX	MOTOR AIR STARTING
3177040RX	SHAFTSHUTOFF VALVE

FCBG51RX

CONTROL 3654718NX

MAIN PIPE 3634057

